

HP StorageWorks

1000/1500 Modular Smart Array Command Line Interface user guide

This guide details the Command Line Interface (CLI), which is used to configure and manage the following products:

- HP StorageWorks 1000 Modular Smart Array (MSA1000)
- HP StorageWorks 1500 Modular Smart Array (MSA1500)

Legal and notice information

© Copyright 2002-2007 Hewlett-Packard Development Company, L.P.

Hewlett-Packard Company makes no warranty of any kind with regard to this material, including, but not limited to, the implied warranties of merchantability and fitness for a particular purpose. Hewlett-Packard shall not be liable for errors contained herein or for incidental or consequential damages in connection with the furnishing, performance, or use of this material.

This document contains proprietary information, which is protected by copyright. No part of this document may be photocopied, reproduced, or translated into another language without the prior written consent of Hewlett-Packard. The information is provided "as is" without warranty of any kind and is subject to change without notice. The only warranties for HP products and services are set forth in the express warranty statements accompanying such products and services. Nothing herein should be construed as constituting an additional warranty. HP shall not be liable for technical or editorial errors or omissions contained herein.

Compaq Computer Corporation is a wholly-owned subsidiary of Hewlett-Packard Company.

Microsoft, MS-DOS, MSWindows, Windows, Windows NT, and Windows XP are U.S. registered trademarks of Microsoft Corporation.

HP StorageWorks 1000/1500 Modular Smart Array Command Line Interface user guide

Contents

About this guide	7
Intended audience	7
Related documentation	7
Document conventions and symbols	7
HP technical support	9
HP-authorized reseller.	9
Helpful websites	9
1 Overview and setup	11
About the CLI	11
CLI commands in redundant configurations	12
CLI command syntax	12
Example command	12
Basic command	12
Command options	12
Overview of CLI storage configuration procedures	13
Accessing the CLI	14
2 Using the CLI	17
Help commands	17
Basic command	17
Command options	17
Example <code>help</code> command and response	17
Example <code>help display_all</code> command and response.	18
Show commands	19
Basic command	19
Command options	19
Example <code>show disks</code> command and response for an MSA1500.	20
Example <code>show unit #</code> command and response	20
Example <code>show globals</code> command and response	21
Example <code>show version</code> command and response	21
Example <code>show version -all</code> command and response	22
Example <code>show this_controller</code> command and response	23
Example <code>show connections</code> command and response	24
Example <code>show preferred_path</code> command and response	24
LUN-related commands	25
Flashing LEDs/locating hard drives	25
Basic command	25
Command options	25
Creating LUNs.	26
Basic command	26
Command options	26
Example command and response to create a single LUN from a group of drives	27
Example command and response to create multiple LUNs on a group of drives	27
Example command and response to create a LUN with an assigned spare	28
Assigning a name or ID to a LUN	28
Basic command	28
Command options	28
Example command and response.	28
Adding a spare to an existing LUN	29
Basic command	29
Command options	29
Example command and response.	29
Deleting LUNs	29

Basic command	29
Command options	29
Example command and response	29
Deleting spares	30
Basic command	30
Command options	30
Example command	30
Recognizing a failed unit	30
Basic command	30
Command options	30
Expanding an array	30
Basic command	30
Command options	30
Example command and response.	30
Extending a LUN	31
Basic command	31
Command options	31
Example command and response.	31
Migrating a LUN to a different RAID level.	31
Basic command	31
Command options	31
Example command and response.	31
Changing the cache setting for a LUN	32
Basic command	32
Command options	32
Example command and response.	32
Setting the preferred path for a LUN	32
Basic command	32
Command options	32
Example command and response.	33
Enabling/disabling automatic path switching	34
Basic command	34
Command options	34
Example command and response.	34
Global commands	35
Setting global variables	35
Basic command	35
Command options	35
Example command and response	36
Setting the controller ID	36
Basic command	36
Command options	36
Example command and response	36
Setting hard addressing	36
Basic command	36
Command options	36
Example command and response	36
Changing the CLI prompt	37
Basic command	37
Command options	37
Example command and response	37
Updating MSA firmware.	37
Disabling a controller for removal	39
Basic command	39
Overriding the ACU lock	39
Basic command	39
Enabling or disabling debug console logging	39
Basic command	39
Host connection commands	40

Adding a connection	40
Basic command	40
Command options	40
Example command and response	40
Changing the profile of a connection	41
Basic command	41
Command options	41
Example command and response	41
Changing the user-defined name of a connection.	41
Basic command	41
Command options	41
Example command and response	41
Deleting the user-defined name of a connection	42
Basic command	42
Command options	42
Example command and response	42
Creating a new profile	42
Basic command	42
Command options	42
Moving to a different profile	42
Basic command	42
Command options	42
Example command.	42
Changing the profile mode	43
Basic command	43
Command options	43
Access Control List commands	43
Viewing the ACL	43
Basic command	43
Example command and response.	43
Adding to the ACL	44
Basic command	44
Command options	44
Example command and response	44
Deleting information from the ACL	44
Basic command	44
Command options	44
Example command and response	44
A Storage overview	45
Arrays and logical drives.	45
Fault-tolerance methods	46
RAID 0—No fault tolerance.	47
RAID 1+0—Drive mirroring.	47
RAID 5—Distributed data guarding	48
RAID 6—Advanced data guarding	48
Comparison of RAID methods.	50
Choosing a RAID level	50
Index	51

Figures

1	Multiple physical drives (D1, D2, and D3) in a system	45
2	Multiple physical drives (D1, D2, and D3) configured into one logical drive (L1)	45
3	Data striping (S1-S4) and data blocks (B1-B12) on multiple physical drives (D1, D2, and D3)	45
4	Two arrays (A1, A2) containing five logical drives (L1 through L5) spread cross five physical drives (D1 through D5)	46
5	RAID 1 array, with two physical hard drives (D1, D2)	47
6	RAID 1+0 array, with eight physical hard drives (D1 through D8)	47
7	RAID 5 array, with three physical hard drives (D1, D2, D3) showing distributed parity information (Px,y)	48
8	RAID 6 array, with four physical hard drives (D1, D2, D3, D4) showing distributed parity information (Px,y)(Qx,y)	49

Tables

1	Document conventions	7
2	CLI special keys	11
3	RAID 0 features	47
4	RAID 1, RAID 1+0 features	48
5	RAID 5 features	48
6	RAID 6 features	49
7	Summary of RAID methods	50
8	Choosing a RAID level	50

About this guide

This user guide provides information to help you use the MSA Command Line Interface (CLI).

Intended audience

This book is intended for use by administrators with a moderate amount of SAN-management experience.

Related documentation

In addition to this guide, see the following related documents:

- MSA1500 compatibility guide
- *HP StorageWorks Modular Smart Array 1500 installation and configuration overview* (printed poster)
- *HP StorageWorks 1500 Modular Smart Array installation guide*
- *HP StorageWorks 1500 Modular Smart Array maintenance and service guide*
- MSA1000 compatibility guide
- *HP StorageWorks Modular Smart Array 1000 installation and configuration overview* (printed poster)
- *HP StorageWorks 1000 Modular Smart Array installation guide*
- *HP StorageWorks 1000 Modular Smart Array maintenance and service guide*
- *HP Array Configuration Utility user guide*
- *Configuring Arrays on HP Smart Array Controllers reference guide*

These and other HP documents can be found on the HP documents website: <http://www.docs.hp.com>.

Document conventions and symbols

Table 1 Document conventions

Convention	Element
Medium blue text: Figure 1	Cross-reference links and e-mail addresses
Medium blue, underlined text (http://www.hp.com)	Website addresses
Bold font	<ul style="list-style-type: none">• Key names• Text typed into a GUI element, such as into a box• GUI elements that are clicked or selected, such as menu and list items, buttons, and check boxes
<i>Italics font</i>	Text emphasis
Monospace font	<ul style="list-style-type: none">• File and directory names• System output• Code• Text typed at the command-line
<i>Monospace, italic font</i>	<ul style="list-style-type: none">• Code variables• Command line variables
Monospace, bold font	Emphasis of file and directory names, system output, code, and text typed at the command line

⚠ **WARNING!** Indicates that failure to follow directions could result in bodily harm or death.

⚠ **CAUTION:** Indicates that failure to follow directions could result in damage to equipment or data.

📌 **IMPORTANT:** Provides clarifying information or specific instructions.

📖 **NOTE:** Provides additional information.

💡 **TIP:** Provides helpful hints and shortcuts.

HP technical support

Telephone numbers for worldwide technical support are listed on the HP support website:
<http://www.hp.com/support/>.

Collect the following information before calling:

- Technical support registration number (if applicable)
- Product serial numbers
- Product model names and numbers
- Applicable error messages
- Operating system type and revision level
- Detailed, specific questions

For continuous quality improvement, calls may be recorded or monitored.

HP strongly recommends that customers sign up online using the Subscriber's choice website at
<http://www.hp.com/go/e-updates>.

- Subscribing to this service provides you with e-mail updates on the latest product enhancements, newest versions of drivers, firmware documentation updates, and instant access to numerous other product resources.
- After signing up, you can quickly locate your products by selecting **Business support** and then **Storage** under Product Category.

HP-authorized reseller

For the name of your nearest HP-authorized reseller:

- In the United States, call 1-800-345-1518.
- Elsewhere, see the HP website: <http://www.hp.com>. Click **Contact HP** to find locations and telephone numbers.

Helpful websites

For third-party product information, see the following HP websites:

- <http://www.hp.com>
- <http://www.hp.com/go/storage>
- <http://www.hp.com/support/>
- <http://www.docs.hp.com>

1 Overview and setup

The Command Line Interface (CLI) is used to configure and manage the MSA array controller and its storage. Some configuration and management tasks include configuring storage units (LUNs), limiting access to the storage, and viewing information on MSA components (controller, unit, and cache).

In addition, the CLI can be used to display system setup information and status. It may also provide information on devices that are attached to the controller.

 **NOTE:** The CLI is available for all supported operating systems.

The CLI is an out-of-band utility, accessed through a host computer connected to the serial port of an MSA controller.

This chapter discusses:

- [About the CLI](#), page 11
- [Accessing the CLI](#), page 14


About the CLI

To use the CLI, enter a command string at the CLI prompt (CLI>). Commands must use a specific, preset syntax. After a command is entered and executed, the results are displayed at the CLI prompt.

When using the CLI, the following keystrokes have special meaning:

Table 2 CLI special keys

Keyboard keys	Arrow key	Meaning
Ctrl+B	Left arrow	Move the cursor back one character
Ctrl+F	Right arrow	Move the cursor forward one character
Ctrl+P	Up arrow	Recall the previous command in the command buffer
Ctrl+N	Down arrow	Recall the next command in the command buffer

 **NOTE:** The CLI uses a zero-based numbering system. For example, LUN number assignments begin with 0.

CLI commands in redundant configurations

When an MSA has two controllers, the same firmware image is run on both controllers. The two controllers communicate with each other through a PCI bus called the inter-controller link (ICL). Each controller has a serial port and has a CLI available to the users who connect the serial port to a serial terminal.

Some CLI commands are entered from one controller's CLI prompt but are executed from the other controller. Command syntax instructs the controller to accept user input, pass the command to the other controller, and then display the result.

The following keywords are used in the CLI to indicate a specific controller:

- `this_controller`—is included in command syntax to refer to the controller that the CLI is connected to.
- `other_controller`—is included in command syntax to refer to the other controller in the MSA.

CLI command syntax

As previously mentioned, commands are entered at the CLI prompt. Commands are **not** case sensitive and must be typed out in full.

CLI command strings include the basic command plus specific command options, some of which are mandatory and some of which are optional.

The CLI does not support line-continuation characters. If all characters of a command do not fit on one line of the CLI, let them wrap around to the next line on the screen. The maximum command length is 255 characters.

Example command

```
add unit 0 data="disk101-disk103" raid_level=0
```

This example command has three portions—the basic command, plus two required command options.

Basic command

```
add unit <#> data="diskrange" raid_level=r
```

The basic command includes a word or phrase used to instruct the controller. Commands usually contain a verb with a noun. Every CLI command must begin with a basic command.

Command options

`#`—the number to assign to the LUN.

`data="diskrange"`—the number of an individual drive or range of drives to incorporate into the LUN. Disks are identified by box number and bay number. For example, `disk101` through `disk103` identifies disks 1 through 3 in box number 1.

`raid_level=r`—the RAID fault-tolerance level to use, where `r` represents:

- 0 = RAID 0 (no fault tolerance)
- 1 = RAID 1 (mirroring)
- 5 = RAID 5 (distributed parity)
- 6 = RAID 6 (advanced data guarding (ADG))


An option is defined as words or phrases listed after the basic command that supply necessary information to support the command. If an option is required but not entered, the CLI command string is considered invalid. If an option is available but not required, a default value is used.

Overview of CLI storage configuration procedures

When using the CLI to initially configure the MSA controller and its storage, use the following sequence:


1. Create the LUNs.

See ["LUN-related commands"](#) on page 25 for command descriptions.

 **NOTE:** OpenVMS environments must assign a unique ID number to each LUN. See ["Assigning a name or ID to a LUN"](#) on page 28 for instructions.


2. Enter array controller settings, including global parameters.

See ["Global commands"](#) on page 35 for command descriptions.

 **NOTE:** OpenVMS environments must assign a unique ID number to each array controller. See ["Setting the controller ID"](#) on page 36 for instructions.

3. Enter connection information about the HBAs with access to the MSA.

See ["Host connection commands"](#) on page 40 for command descriptions.

 **NOTE:** Each host accessing the storage must identify its operating system (profile type.) See ["Changing the profile of a connection"](#) on page 41 for instructions.

4. (Optional) Limit access to the storage.

See ["Access Control List commands"](#) on page 43 for command descriptions.

Accessing the CLI

The CLI is accessed through a host computer connected to the serial port of an MSA controller.

Use the following steps to establish a serial connection to the controller:


1. Make sure there is an MSA controller installed in Slot 1 of the unit (Slot 1 is located on the front right of the unit). In multipathing configurations, two MSA controllers must be installed.
2. Connect the MSA controller to a host using the custom serial cable included in the shipping carton of the MSA.

An additional or replacement custom serial cable can be ordered using part number 259992-001.

3. Set up a terminal emulator.

Depending on the host operating system, different emulators are available. For example, Linux uses Minicom and Microsoft Windows uses HyperTerminal. Setup procedures for emulators differ—the following instructions are for setting up HyperTerminal:

- a. Click **Start > All Programs > Accessories > Communications > HyperTerminal** to open HyperTerminal.




- b. In the HyperTerminal **New Connection** dialog box, type a name to associate with the connection between the controller and the host, then click **OK**.

The **Connect To** dialog box is displayed.



- c. Expand the **Connect using** drop-down box, select a COM port, and then click **OK**.

The **COM Properties** dialog box is displayed.



- d. Enter the following settings, and then click **OK**.

Bits per Second: 19200

Data bits: 8

Parity: None

Stop bits: 1

Flow control: None

The CLI input screen is displayed.

- e. Press **Enter** several times to display the command prompt (CLI>).
Commands can now be entered at this CLI prompt.

2 Using the CLI

Managing and configuring the MSA and its storage includes configuring LUNs, entering connection information, limiting access to the storage, and viewing information about the configuration.

This chapter is organized in the order in which the commands are used when configuring a new MSA installation.

- [Help commands](#), page 17
- [Show commands](#), page 19
- [LUN-related commands](#), page 25
- [Global commands](#), page 35
- [Host connection commands](#), page 40
- [Access Control List commands](#), page 43

Help commands

Help commands can be used to display a list of all possible commands or a detailed description of a specific command. Displayed information may include required command syntax, a brief definition, the number of characters for a command option value, or a list of allowed/disallowed characters.

The basic command is `help`. It can be modified to narrow the request.

Basic command

```
help [CommandNoun|CommandVerb] [display_all]
```

Command options

`CommandNoun|CommandVerb`—information about the specified command verb or noun will be displayed.

`display_all`—a list of all currently supported commands will be displayed.

Example `help` command and response

```
CLI> help
```

Possible command verbs:

	help	add
copy	change	download
delete	migrate	expand
extend	accept	rename
set	locate	show
disable	start	stop
clear	override	

Possible command nouns:

unit	units	connection
acl	profile	mode
spare	firmware	unit_id
this_controller	this_controller_id	other_controller
other_controller_id	globals	prompt
disk	bus	box
all	cancel	connections
version	disks	tech_support
standby	preferred_path	auto_path_change
proxystats	this_controller_hard_address	
perf		
cacheinfo	taskstats	debug
eventlot	aculock	

Example help display_all command and response

```
CLI> help display_all
```

```
Displaying list of all currently supported CLI commands:
```

```
? help
add unit add units
add connection add acl
add profile copy profile
change mode add spare
download firmware delete unit
delete units delete connection
delete acl delete profile
delete spare migrate unit
expand unit extend unit
accept unit accept units
rename connection set unit_id
set this_controller set this_controller_id
set other_controller set other_controller_id
set globals set acl
set connection set prompt
set unit locate disk
locate unit locate bus
locate box locate all
locate cancel show connections
show unit show units
show unit_id show this_controller
show other_controller show version
show disks show version -all
show acl show globals
show tech_support show profile
disable other_controller disable standby
Show preferred_path disable this_controller
show auto_path_change set preferred_path
show proxystats set auto_path_change
set this_controller_hard_address show this_controller_hard_address
start perf show perf
clear perf stop perf
show taskstats show cacheinfo
show eventlog set debug
show aculock override aculock
```

Show commands

The `show` command is used to view MSA configuration and status information. A few samples are provided in the following paragraphs.

Basic command

```
show [acl] [aculock] [cacheinfo] [connections] [disks] [eventlog] [globals]
[other_controller] [perf] [preferred_path] [profile] [proxystats] [taskstats]
[tech_support] [this_controller] [unit #] [unit_id #] [units] [version]
```

Command options

`acl`—displays information about the access control lists, including whether they are enabled or disabled, the connection name, `wwpn`, and LUNs they are permitted to access.

`aculock`—displays the status of the ACU lock.

`cacheinfo`—displays MSA controller cache information.

`connections`—displays information about the HBA connections to the MSA, including the user-defined name, `wwpn`, and operating system profile.

`disks`—displays information about the hard drives connected to the MSA, including: disk number, enclosure box and bay number, enclosure bus number, disk size, LUN in which the disk is used, and disks assigned as spares.

`eventlog`—displays MSA event log.

`globals`—displays global information about the MSA chassis, including the user-defined system name, rebuild/expand priority settings, read/write cache settings, and temperature readings.

`other_controller`—displays information about the MSA controller, including: the user-defined controller ID, hardware build number, controller firmware version, SCSI ID, redundancy settings, cache settings, and battery information.

`perf`—displays MSA performance analysis information.

`preferred_path`—(dual-controller, active/active configurations only) displays the controller path for the LUNs.

`profile`—displays information about the profiles assigned to the HBAs connected to the MSA.

`proxystats`—(dual-controller, active/active configurations only) displays information about commands that have been passed from one controller to the other through the intercontroller link (ICL) during the past 30 minutes.

`taskstats`—displays MSA task statistics information.

`tech_support`—displays a summary of system information, executing the following commands in a batch: `show disks`, `show units`, `show this_controller`, `show other_controller`, `show cacheinfo`, `show globals`, `show version`, `show profile`, `show acl`, `show connections`, and `show eventlog`.

`this_controller`—displays information about the MSA controller, including: the user-defined controller ID, hardware build number, controller firmware version, SCSI ID, redundancy settings, cache settings, and battery information.

`unit #`—displays information about a specific LUN, including: the LUN ID, status, list of hard drives included in the LUN, list of hard drives assigned as spares to the LUN, RAID level, and LUN size.

`unit_id #`—displays the user-defined name assigned to a LUN.

`units`—displays information about all configured LUNs, including: the LUN ID, status, list of hard drives included in the LUN, list of hard drives assigned as spares to the LUN, RAID level, and LUN size.

`version`—displays version information, including: hardware build, controller firmware, and fan module firmware.

`version -all`—displays individual hard drive firmware versions, in addition to what the `version` command shows.

Example show disks command and response for an MSA1500

```
CLI> show disks
```

```
Disk List:   (box,bay)  (B:T:L:)   Size      Speed      Units
Enclosure 1: SATA                                SATA      PROLIANT 8LCE
Disk101     (1,01)      (0:03:01)  250.0GB   160 MB/s   none
Disk102     (1,02)      (0:03:02)  250.0GB   160 MB/s   none
Disk103     (1,03)      (0:03:03)  250.0GB   160 MB/s   none
Disk104     (1,04)      (0:03:04)  250.0GB   160 MB/s   none
Disk105     (1,05)      (0:03:05)  250.0GB   160 MB/s   none
Disk106     (1,06)      (0:03:06)  250.0GB   160 MB/s   none
Disk107     (1,07)      (0:03:07)  250.0GB   160 MB/s   none
Enclosure 2: SCSI                                PROLIANT  PROLIANT 4LEE
Disk201     (2,01)      (1:00:00)  250.0GB   160 MB/s   none
Disk202     (2,02)      (1:01:00)  250.0GB   160 MB/s   none
Disk203     (2,03)      (1:02:00)  250.0GB   160 MB/s   none
Disk204     (2,04)      (1:03:00)  250.0GB   160 MB/s   none
Disk205     (2,05)      (1:04:00)  250.0GB   160 MB/s   none
Disk206     (2,06)      (1:05:00)  250.0GB   160 MB/s   none
```

Example show unit # command and response

```
CLI> show unit 1
```

```
Unit 1:
```

```
In PDLA mode, Unit 1 is LUN 2; In VSA mode, Unit 1 is LUN 1
```

```
Unit Identifier:
```

```
Device Identifier:          600805F3-00006B20-AE277D4B-B0D100F7
```

```
Preferred Path:            Controller 1 (this controller)
```

```
Cache Status:              Enabled
```

```
Max Boot Partition:        Disabled
```

```
Volume Status:              VOLUME OK
```

```
Parity Init Status:        3% complete
```

```
5 Data Disk(s) used by lun 1:
```

```
  Disk107:                  Box 1, Bay 07, (B: T: L: 2;04:07)
```

```
  Disk108:                  Box 1, Bay 08, (B: T: L: 2;04:08)
```

```
  Disk207:                  Box 2, Bay 07, (B: T: L: 2;04:07)
```

```
  Disk208:                  Box 2, Bay 08, (B: T: L: 2;04:08)
```

```
Spare Disk(s) used by lun 1:
```

```
  No spare drive is designated
```

```
Logical Volume Raid Level:  DISTRIBUTED PARITY FAULT TOLERANCE  
                             (RAID5)
```

```
stripe_size=16KB
```

```
Logical Volume Capacity:    173,658MB
```

Example show globals command and response

```
CLI> show globals
```

Global Parameters:

```
System Name:          MSA-1
Rebuild Priority:     medium
Expand Priority:      medium
Surface Delay:       3.0 seconds
Total Cache:         256MB
50% Read Cache:      128 MB
50% Write Cache:     128 MB
```

Temperature:

```
EMU:                  30 Celsius, 86 Fahrenheit
PS1:                  40 Celsius, 104 Fahrenheit
PS2:                  40 Celsius, 104 Fahrenheit
```

Example show version command and response

```
CLI> show version
```

```
MSA 1500 Firmware Revision: 6.86b1
MSA 1500 Firmware Revision: 7
Fibre Module AutoRev:      0x020000
SCSI I/O Module Bus 0 Revision: 2.02
SCSI I/O Module Bus 1 Revision: 2.02
SCSI I/O Module Bus 2 Revision: 2.02
SCSI I/O Module Bus 3 Revision: 2.02
Fan Control Module A Revision: 2.38
Fan Control Module B Revision: 2.38
```

Example show version -all command and response

```
CLI> show version -all
```

```
MSA 1500 Firmware Revision:      5.10b414 (SGA0434084)
MSA 1500 Firmware Revision:      7 [AutoRev: 0x010000]
Fibre Module AutoRev:            0x020000
SCSI I/O Module Bus 0 Revision:  2.02
SCSI I/O Module Bus 1 Revision:  2.02
SCSI I/O Module Bus 2 Revision:  2.02
SCSI I/O Module Bus 3 Revision:  2.02
Fan Control Module A Revision:    2.38
Fan Control Module B Revision:    2.38
Box 1a PROLIANT 4L7E*DB Rev:     2.30 (Z8LCLMPY47)
Box 1b PROLIANT 4L7E*DT Rev:     CP20 (Z8LCLMPY47)
Box 3b PROLIANT 4L7E*DT Rev:     CP20 (TERJE2BOX2)
Box 3a PROLIANT 4L7E*DB Rev:     2.30 (TERJE2BOX2)
```

Disk Drives:


B	T	L	BOX	BAY	GB Model	Rev.	Serial No.
0	0	0	1	1	146.8 COMPAQ	BD146863B3	HPB8 B8LX86HM
0	0	0	1	1	146.8 COMPAQ	BD146863B3	HPB8 B8LX8EFM
0	8	0	1	7	146.8 COMPAQ	BD14686225	HPB6 P01P4707AGE0431

Example show this_controller command and response

```
CLI> show this_controller

Controller 1 (right controller):
  MSA1500 c Hewlett-Packard xxx Version 6.86 Build 122 Hardware 7
  Component Enclosure.
  Controller Identifier:
  NODE_ID=yyyyyyyyy-yyyyyyyyy
  SCSI_VERSION=SCSI-3
  Supported Redundancy Mode: Active/Standby Asm-Active/Active
  Current Redundancy Mode: Asym-Active/Active
  Device Port SCSI address 6
  Terminal speed for the CLI is set to 19200.
Host Port_1:
  REPORTED PORT_ID YYYYYYYYYY-YYYYYYYYY
  PORT_1_TOPOLOGY=F_Port
Cache:
  128 megabytes read cache 128 megabytes write cache Version 2
  Cache is GOOD, and Cache is enabled
  No unflushed data in cache
Battery:
  Module #1 is fully charged and turned off.
Controller Up Time:
  5 Days 06 Hours 01 Minutes 51 Seconds
Health:
  Surface Scan:    Complete.
  Rebuild Status: Complete.
  Expansion:       Complete.
```

Example show connections command and response

 **NOTE:** Use the `show connections` command to verify that all connections to the MSA are recognized and defined, including the profile type.

```
CLI> show connections
```

```
Connection Name: <unknown>
Host WWNN = 11111111-11111111
Host WWPN = 22222222-22222222
Profile Name = Windows
Unit Offset = 0
Controller 1 Port 1 Status = Online
Controller 2 Port 1 Status = Offline
```

```
Connection Name: <unknown>
Host WWNN = 33333333-33333333
Host WWPN = 44444444-44444444
Profile Name = Windows
Unit Offset = 0
Controller 1 Port 1 Status = Online
Controller 2 Port 1 Status = Offline
```

Example show preferred_path command and response

```
CLI> show preferred_path
```

```
Controller 1 (this_controller) is the current optimal path for these units;
0,1,4,5
```

```
Controller 2 (other_controller) is the current optimal path for these units;
2,3,6,7
```

```
Implicit (automatic load-based) LUN ownership changes are currently
DISABLED.
```

```
Controller 1 (this_controller) is the explicit power-up path for these
units; 0,1,4,5
```

```
Controller 2 (other_controller) is the explicit power-up path for these
units; 2,3,6,7
```


LUN-related commands

The following commands are used to physically locate specific hard drives in a LUN as well as create, delete, and modify storage LUNs.

- Flashing LEDs/locating hard drives
- Creating LUNs
- Assigning a name or ID to a LUN
- Adding a spare to an existing LUN
- Deleting LUNs
- Deleting spares
- Recognizing a failed unit
- Expanding an array
- Extending a LUN
- Migrating a LUN to a different RAID level
- Changing the cache setting for a LUN
- Setting the preferred path for a LUN
- Enabling/disabling automatic path switching

Flashing LEDs/locating hard drives

A variety of commands are available for physically locating specific hard drives. You can precisely locate all drives attached to the MSA, all drives in an exact storage enclosure, all drives on a specific SCSI bus, all drives in a specific LUN, or a particular hard drive.

When these commands are executed, the LEDs of the requested drives will blink. These LEDs are visible from the front of the MSA and its attached storage enclosures.

 **NOTE:** If a time limit is not included with the `locate` command, the LEDs will blink for 30 seconds.

The basic command verb is `locate`, but a variety of command nouns and command options are available to customize the request.

Basic command

```
locate [all] [box x] [bus x] [cancel] [disk diskxxx] [disk diskxxx-diskyyy]
[time=t] [unit x]
```

Command options

`all`—all drives connected to the MSA storage subsystem will be located.

`box x`—the number of the storage enclosure whose disks you want to locate. This option applies only to the MSA1000.

- 1—the MSA1000 drive shelf
- 2—the storage enclosure attached to SCSI port A
- 3—the storage enclosure attached to SCSI port B

`bus x`—the number of the bus whose disks you want to locate. This option applies only to the MSA1000.

`cancel`—immediately turns off all location LEDs.

`disk diskxxx`—a specific drive to locate. Disks are identified by box number and bay number.

`disk diskxxx-diskyyy`—a range of drives to locate. Disks are identified by box number and bay number.

`time=t`—(optional) the length of time to flash the LEDs, where *t* represents the number of seconds. This option must be preceded by another option such as `all`.

`unit x`—the number of the LUN whose disks you want to locate.

Creating LUNs

A LUN is a logical storage unit comprised of one or more hard drives.

When a LUN is initially created, the LUN Unit ID is automatically set to the same number assigned to the LUN. If desired, this LUN ID name can be changed. See “Assigning a name or ID to a LUN” on page 28 for procedural information.

The basic command is `add unit`. A variety of options are available to modify the command.


Basic command

```
add unit[s] <#> <data="diskrange"> <raid_level=r> [spare="diskrange"]  
[stripe_size=s] [size=s<GB|MB>] [max_boot=<enable/disable>]  
[cache=<enable/disable>]
```

Command options


`#`—the number to assign to the LUN.

`data="diskrange"`—the number of an individual drive or range of drives to incorporate into the LUN. Disks are identified by box number and bay number. For example, disk110 identifies disk 10 in box number 1, and disk101-disk105 identifies disks 1 through 5 in box number 1.

 **NOTE:** Quotation marks must be entered both before and after the data disk drives that are to be included in the LUN.

`raid_level=r`—the RAID fault-tolerance level to use, where `r` represents:

- 0 = RAID 0 (no fault tolerance)
 - 1 = RAID 1 (mirroring)
 - 5 = RAID 5 (distributed parity)
 - 6 = Advanced Data Guarding (ADG)
-

 **NOTE:** If more than one pair of drives are included in a RAID 1 array, the data is striped across the first half of the drives in the array, and then each drive is mirrored to a drive in the remaining half of the drives for fault tolerance. This method is referred to as RAID 1+0.

`stripe_size=s`—(optional) the stripe size to assign (in KB), where `s` represents 8, 16, 32, 64, 128, or 256 Kilobytes.

- RAID 0 uses stripe sizes 8, 16, 32, 64, 128, and 256 (Default: 128 KB)
- RAID 1 uses stripe sizes 8, 16, 32, 64, 128, and 256 (Default: 128 KB)
- RAID 5 uses stripe sizes 8, 16, 32, and 64 (Default: 16 KB)
- RAID 6 uses stripe sizes 8, 16, 32, and 64 (Default: 16 KB)

`size=syy`—(optional) how much of the available space on the indicated drives is to be used for the LUN, where `s` represents the LUN size, and `yy` indicates MB or GB. (When GB is entered, all return displays will be converted to MB.) If no size is specified, the maximum available space of the included disks, up to 2 TB, will be assigned to the unit.


`spare="diskrange"`—(optional) disk(s) to assign as a spare to the unit, where `diskrange` represents the disk number. More than one disk can be assigned as a spare to a LUN. And, the same drive can be assigned as an available spare to several different LUNs.

`maxboot=enable|disable`—(optional) changes the size of the boot partition.

- Enable = (default) 8-GB boot partition
- Disable = 4-GB boot partition

`cache=enable|disable`—(optional) determines whether to use the array controller cache for the LUN.

- Enable = (default) use the array controller cache
- Disable = do not use the array controller cache

 **IMPORTANT:** Maintain a record of the units as they are created. These unit numbers are used in other CLI commands. In addition to recording the unit number, the drives included, RAID type and size, **record the order in which they are created.**

Example command and response to create a single LUN from a group of drives

```
CLI> add unit 0 data="disk101-disk107 disk110" raid_level=6 stripe_size=64
```

```
First volume to be configured on these drives.  
Logical Unit size = 69460 MB  
RAID overhead = 0 MB  
Total space occupied by new unit = 69460 MB  
Free space left on this volume = 0 MB  
Unit 0 is created successfully.
```

Example command and response to create multiple LUNs on a group of drives

```
CLI> add unit 1 data="disk111-disk114" raid_level=5 stripe_size=32  
size=1000mb
```

```
First volume to be configured on these drives.  
The logical unit size has been adjusted by 4MB for optimal performance.  
Logical Unit size = 996 MB  
RAID overhead = 498 MB  
Total space occupied by new unit = 1494 MB  
Free space left on this volume = 24533 MB  
Unit 1 is created successfully.
```

```
CLI> add unit 2 data="disk111-disk114" raid_level=5 stripe_size=32  
size=2000mb
```

```
Logical Unit size = 2000 MB  
RAID overhead = 1000 MB  
Total space occupied by new unit = 3000 MB  
Free space left on this volume = 21533 MB  
Unit 2 is created successfully.
```

```
CLI> add unit 3 data="disk111-disk114" raid_level=5 stripe_size=16  
size=4000mb
```

```
Logical Unit size = 4000 MB  
RAID overhead = 2000 MB  
Total space occupied by new unit = 6000 MB  
Free space left on this volume = 15533 MB  
Unit 3 is created successfully.
```

Example command and response to create a LUN with an assigned spare

```
CLI> add unit 4 data="disk211-disk212" raid_level=1 spare="disk213"
```

First volume to be configured on these drives.

Logical Unit size = 69460 MB

RAID overhead = 69460 MB


Total space occupied by new unit = 138920 MB

Free space left on this volume = 0 MB

Unit 4 is created successfully.

Assigning a name or ID to a LUN

If desired (or required by your operating system), each LUN can be assigned a unique name or ID, in addition to its number. These user-defined names make it easier to identify specific LUNs in other configuration procedures.

 **NOTE:** OpenVMS systems require each LUN to have a unique ID. No two devices in the entire SAN for the OpenVMS systems may share ID numbers. LUNs in different storage systems must have different IDs. LUN IDs in OpenVMS systems must be numeric.

Basic command

```
set unit_id <#> <identifier>
```

Command options

#—the number of the LUN that is being assigned a name.

identifier—name or number to assign to the specified LUN. The ID can be up to 230 alphanumeric characters or a decimal number in the range of 0 though 65535. If spaces are included in the name, quotation marks are required.

Example command and response

```
CLI> set unit_id 1 1523
```

Device identifier "1523" created.

Adding a spare to an existing LUN

Basic command

```
add spare unit=<#> <diskrange>
```

Command options

#—the unit to assign the spare to. This is the same number that was given to the unit when it was created with the `add unit` command.


diskrange—indicates the drives to assign as the spare to the LUN. Disks are identified by box number and bay number.

Example command and response

```
CLI> add spare unit=2 disk112

Available write cache lines: 0x37FD (592458:592420)
Available read cache lines: 0x37EE
Using write cache lines 0x0 to 0x1BFD
Hiding write cache lines 0x1BFE to 0x37FC
Using read cache lines 0x37FD to 0x53F3
Hiding read cache lines 0x53F4 to 0x6FEA
Spare drive(s) has been added. Use 'show unit 0' to confirm.
```

Deleting LUNs

 **NOTE:** A LUN cannot be deleted if there are other LUNs after it. For example, if LUNs 0-3 are configured, LUN 1 cannot be deleted without also deleting LUNs 2 and 3.

After a LUN is deleted, its unit number goes unused until manually assigned to a new LUN. Unit numbers are not automatically reassigned when a LUN is deleted.

Basic command

```
delete unit <#> [-y]
```

Command options

#—the unit or range of units to delete. This is the same number that was given to the unit when it was created with the `add unit` command.

-y—(optional) no user confirmation is required before the deletion is made.

Example command and response

```
CLI> delete unit 4
```

```
Data will be lost after the unit is deleted.
Do you still want to DELETE unit 4 (Y/N)? Y
Please wait while unit 4 is being deleted..
Unit 4 is deleted successfully.
```

Deleting spares

Basic command

```
delete spare unit <#> <diskrange>
```

Command options

`unit #`—the unit that will no longer have access to the spare. This is the same number that was given to the unit when it was created with the `add unit` command.

`diskrange`—the spare drive or range of spares to remove from use. Disks are identified by box number and bay number.

Example command

```
CLI> delete spare unit=2 disk109
```

Recognizing a failed unit

If all drives of a previously failed unit are in working order, use this command to change the state of the unit back to `VOLUME_OK`.

To accept media exchange on a unit marked as failed:

Basic command

```
accept unit <#>
```

Command options

`#`—the unit that you want to activate, where `#` represents the unit number.

Expanding an array

△ **CAUTION:** In an HP-UX environment, expanding a LUN, as described in this section, is not supported. See the HP-UX documentation for instructions on expanding LUNs on an HP-UX system.

To add additional physical drives to an array:

📖 **NOTE:** Because this command affects the entire array, all LUNs made from the array are also affected.

Basic command

```
expand unit <#> <diskrange>
```

Command options

`#`—one of the LUN within the target array.

📖 **NOTE:** Any LUN in the array can be entered to identify the array; the space is added to the array and not the LUN.

`diskrange`—the physical disks to add to the array. Disks are identified by box number and bay number.

Example command and response

```
CLI> expand unit 4 disk204-disk207
```

The actual new array capacity will be 3000MB.
The array with Unit 4 is being expanded.
Use "show unit 4" to monitor progress.

Extending a LUN

- △ **CAUTION:** In an HP-UX environment, extending a LUN as described in this section is not supported. See the HP-UX documentation for instructions on extending LUNs on an HP-UX system.

To incorporate unused, available space in an array to a specific LUN:

Basic command

```
extend unit <#> [new_size=syy|add_size=syy]
```

Command options

#—the LUN to which the space will be added.

add_size=syy—how much of the available space in the array to add to the LUN, where s represents the size, and yy indicates GB, MB, or KB. If no size is specified, the maximum available space of the included disks will be assigned to the array.

new_size=syy—can be used instead of add_size to enter the total new size of the LUN, where s represents the size, and yy indicates GB, MB, or KB.

Example command and response

```
CLI> extend unit 2 add_size=1000mb
```

The actual new volume size will be 1992MB.

Unit 2 is being extended.

Use "show unit 2" to monitor progress.

Migrating a LUN to a different RAID level

While obeying the constraints of included number of drives and applicable stripe sizes, you can migrate an array from one RAID level to another. If you attempt to move to an unsupported RAID configuration for an array, an error message is displayed.

- 📋 **NOTE:** Before changing the RAID level or stripe size of a LUN, verify there is available, unused space on the array. Migrating from one RAID level to another may require additional space for parity and organizational purposes.

Basic command

```
migrate unit <#> [raid_level=r] [stripe_size=s]
```

Command options

#—the number of the LUN to modify.

raid_level=r—the RAID level to migrate to. RAID levels include:

0 = RAID 0 (no fault tolerance)

1 = RAID 1 (mirroring)

5 = RAID 5 (distributed parity)

6 = RAID 6 (advanced data guarding (ADG))

stripe_size=s—(optional) the stripe size to use. Options include:

RAID 0 can use stripe sizes 8, 16, 32, 64, 128, and 256 (Default: 128 KB)

RAID 1 can use stripe sizes 8, 16, 32, 64, 128, and 256 (Default: 128 KB)

RAID 5 can use stripe sizes 8, 16, 32, and 64 (Default: 16KB)

RAID 6 can use stripe sizes 8, 16, 32, and 64 (Default: 16 KB)

Example command and response

```
CLI> migrate unit 0 raid_level=5 stripe_size=32
```

The RAID level of Unit 0 will now be 5.
Unit 0 is being migrated.
Use "show unit 0" to monitor progress.

Changing the cache setting for a LUN

To enable or disable the array accelerator cache for a specific LUN:

Basic command

```
set unit <#> <cache=[enable|disable]>
```

Command options

#—the number of the LUN to modify. In this example, LUN 0 will be modified.


cache=enable|disable—either enables or disables the use of the array accelerator cache for the specified LUN.

Example command and response

```
CLI> set unit 0 cache=enable
```

Cache for unit 0 has been enabled.

Setting the preferred path for a LUN

 **NOTE:** This command is available only with active/active firmware (v6.x or later).

Configures an explicit preferred controller path for specified logical units. Host requests that are directed to the non-preferred controller will be delayed slightly, due to data and command transfer through the inter-controller link.

If implicit path changes are enabled (see "Enabling/disabling automatic path switching" on page 34), controller firmware may automatically switch controller paths for unit(s) based on host request load.

Basic command

```
set preferred_path [controller] [reset] <unit_list>
```

Command options

controller—indicate the controller by entering this_controller, other_controller, controller=1, or controller=2.

reset—restore the last explicitly configured path for the specified LUNs.


unit_list—indicate the LUNs to set by entering all, the unit number of a specific LUN, or a range of unit numbers.

Example command and response

```
CLI> set preferred_path this_controller 0-9

SetPreferredPath start... change_map=0x2FF, lun_to_ctlr_map=0x3FF
POST_Do_Msg: 67 CACHE HARDWARE TEMPORARILY DISABLED
Quiescing host I/O for LUN map 0xFFEFF...
Host/proxy I/O quiesced...
Quiescing host I/O for LUN map 0xFFF00100...
Host/proxy I/O quiesced...
Quiescing cache flush task...
Quiescing background I/O...
Background quiesced...
Flipping ownership(s)... change_map=0x2FF, lun_to_ctlr_map=0x3FF
POST_Do_Msg: 41 REDUNDANCY ACTIVE ACTIVE CONTROLLER
Preferred path for unit 0 is now controller 1 (this_controller)
Preferred path for unit 1 is now controller 1 (this_controller)
Preferred path for unit 2 is now controller 1 (this_controller)
Preferred path for unit 3 is now controller 1 (this_controller)
Preferred path for unit 4 is now controller 1 (this_controller)
Preferred path for unit 5 is now controller 1 (this_controller)
Preferred path for unit 6 is now controller 1 (this_controller)
Preferred path for unit 7 is now controller 1 (this_controller)
Preferred path for unit 9 is now controller 1 (this_controller)
Resuming I/O...
I/O Resumed...
POST_Do_Msg: 65 CACHE HARDWARE ENABLED
```

Enabling/disabling automatic path switching

 **NOTE:** This command is available only with active/active firmware (v6.x or later).

If implicit path changes are enabled, controller firmware will automatically determine and, as needed, switch controller paths for units based on host request load, according to the specified preferences.

Basic command

```
set auto_path_change <enable|disable> [prp=#] [mnr=#] [twp=#] [twl=#]
```

Command options

`enable|disable`—enables or disables implicit path switching.

`prp`—specify a proxied percentage (# = 51-100). This is the minimum percentage of proxied requests required to trigger implicit path change.

`mnr`—specify the minimum number of requests that must be issued to the LUN before path changes are enabled (the number is rounded up to the next highest power of two).

`twp`—specify the minimum number of minutes (0-255) to wait at power-up before changing LUN ownership.

`twl`—specify the minimum number of minutes (0-255) to wait before changing LUN ownership again for same unit.

Example command and response

```
CLI> set auto_path_change disable
```

```
Implicit (automatic load-based) LUN ownership changes are currently  
DISABLED.
```

```
CLI> set auto_path_change enable
```

```
Implicit (automatic load-based) LUN ownership changes are currently ENABLED.
```

```
Implicit LUN ownership change preferences are as follows:
```

```
Minimum % of proxied requests to trigger implicit path change...: 75%
```

```
Minimum number of requests to LUN before path change enabled...: 65536
```

```
Minimum time to wait before changing ownership after power-up...: 30 minutes
```

```
Minimum time between ownership changes for LUN.....: 30 minutes
```

```
CLI> set auto_path_change twp=15
```

```
Implicit (automatic load-based) LUN ownership changes are currently ENABLED.
```

```
Implicit LUN ownership change preferences are as follows:
```

```
Minimum % of proxied requests to trigger implicit path change...: 75%
```

```
Minimum number of requests to LUN before path change enabled...: 65536
```

```
Minimum time to wait before changing ownership after power-up...: 15 minutes
```

```
Minimum time between ownership changes for LUN.....: 30 minutes
```

Global commands

The CLI provides the ability to configure the MSA controller, enter global settings, and perform system-wide commands, including:

- [Setting global variables](#)
- [Setting the controller ID](#)
- [Setting hard addressing](#)
- [Changing the CLI prompt](#)
- [Updating MSA firmware](#)
- [Disabling a controller for removal](#)
- [Overriding the ACU lock](#)
- [Enabling or disabling debug console logging](#)

Setting global variables

A single command with a variety of parameters is used to set the expand priority, the read/write ratio, and the system name.

Basic command

```
set globals [expand_priority=p] [rebuild_priority=r] [system_name="name"]  
[read_cache=r] [write_cache=w]
```

Command options

`expand_priority=p`—the expand priority, where `p` represents the priority setting of low, medium, or high. Used when expanding an array to set the priority of array expansions in relation to input/output operations. See below for detailed information about these settings.


`rebuild_priority=p`—the rebuild priority, where `p` represents the priority setting of low, medium, or high. Used when rebuilding an array to set the priority of an array rebuild in relation to input/output operations. See below for detailed information about these settings.

- `low`—expansion or rebuild takes place only when the array controller is not busy handling normal I/O requests. This setting has minimal effect on normal I/O operations. However, there is an increased risk that data will be lost if another physical drive fails while the rebuild is in progress.
- `medium`—expansion or rebuild occurs for half of the time, and normal I/O requests are handled during the rest of the time.
- `high`—rebuild or expansion occurs at the expense of normal I/O operations. Although system performance is affected, this setting provides better data protection because the array is vulnerable to additional drive failures for a shorter time.

`system_name="name"`—the system name, where `"name"` represents any user defined phrase, up to 20 alphanumeric characters. Quotation marks are required around the name.

`read_cache=r`—the read cache, where `r` specifies the read cache as a percentage of the total cache.

`write_cache=w`—the write cache, where `r` specifies the write cache as a percentage of the total cache.

 **NOTE:** The sum of `read_cache` and `write_cache` must equal 100.

Example command and response

```
CLI> set globals expand_priority=medium
rebuild_priority=medium system_name="MSA-1"
read_cache=50 write_cache=50
```


Global

Parameters:

```
System Name:      MSA-1
Rebuild Priority: medium
Expand Priority:  medium
Total Cache:     256MB
50% Read Cache:  256MB
50% Write Cache: 256MB
```

Setting the controller ID

This command can be used to assign a unique name to each controller installed in the MSA.

 **NOTE:** In OpenVMS environments, a unique identifier must be assigned to each MSA controller. The value must be numeric.

Basic command

```
set this_controller_id <identifier>
-or
set other_controller_id <identifier>
```

Command options

identifier—the user-defined ID for the controller. The ID can be up to 230 alphanumeric characters or a decimal number in the range of 0 through 65535. If spaces are included in the name, quotation marks are required.

Example command and response

```
CLI> set this_controller_id MSA-1
Controller identifier MSA-1 created.
```

Setting hard addressing

To enable or disable Fibre Channel Arbitrated Loop hard addressing on an MSA controller:

Basic command

```
set this_controller_hard_address <enable|disable> <loop_id>
```

Command options

enable|disable—enables or disables hard addressing on the controller.
loop_id—a decimal number between 0 and 125 to assign the loop identifier.

Example command and response

```
CLI> set this_controller_hard_address enable 1
Hard Addressing is enabled.
Loop ID = 1, ALPA = 0xE8
```

Changing the CLI prompt

To temporarily change the CLI prompt from the default of “CLI>”:

Basic command

```
set prompt <new_prompt>
```

Command options

`new_prompt`—the user-defined name for the prompt (up to 24 alphanumeric characters).


Example command and response

```
CLI> set prompt MSA-1
```

```
MSA-1>
```


Updating MSA firmware

Periodically, HP releases updated versions of MSA controller firmware. Updates may include: additional features and functions, performance enhancements, and fixes to known issues. In addition to MSA1000 and MSA1500 components, this command can also be used to update components on attached MSA20 storage enclosures.

 **NOTE:** Because this updating method uses an out-of-band serial connection to the MSA, it is substantially slower than in-band Fibre Channel updating methods.


If possible, HP recommends using the Fibre-Channel updating method for your operating system.

Operating system	In-band utility (Fibre Channel)	Out-of-band utility (Serial)
Windows ProLiant host	MSA Flash Utility	MSA CLI
Linux ProLiant host	MSA Flash Utility	MSA CLI
HP-UX host	SCSI Command Utility (SCU) Array Configuration Utility CLI (ACU-CLI)	MSA CLI
OpenVMS host	MSA_Util	MSA CLI not tested
Tru64 UNIX host	SCSI CAM Utility (SCU)	MSA CLI not supported

 **CAUTION:** Before using this method to update the firmware, make note of the following requirements:

- A full backup of *all* data on the MSA array being updated is required.
- A copy of the array configuration, including all the information used to create the units, is needed for the update.
- If it has been more than six months since you restarted your MSA storage system, HP recommends that you power-cycle the MSA (power off, and then power on) before updating the firmware to ensure that you are working with a fresh system.
- The MSA must be power-cycled after updating the firmware to activate the new firmware.
- When performing an online update for active/passive configurations, ensure that the front-right controller is the active one. The firmware update may not work properly if the front-left controller is active during the update, especially if the update is performed via serial cable.
- Existing firmware on MSA1000 controllers must be v4.32 or higher.
- Existing firmware on MSA1500 controllers must be v4.94 or higher.
- Host computer must support the 1k Xmodem (Ymodem) protocol.
- Because firmware updates require a restart of the MSA and its attached storage enclosures, perform MSA controller firmware updates only during a scheduled maintenance window.

- For newly installed MSA, do not perform a firmware update until the controller batteries are fully charged.
 - For existing MSA, do not perform a firmware update until you have confirmed that the “host mode” or “profile” for each connection is correctly set. The host mode identifies the operating system of each HBA connection to the storage. Do not use the “default” setting. If the host mode is not properly set, hosts may lose access to the storage or experience other difficulties after the update. Use the `show connections` and `set connection` commands to view and change the profile.
 - After performing an update, confirm that the “host mode” or “profile” for each connection is still set correctly. Use the `show connections` and `set connection` commands to view and change the profile.
 - HP-UX environments must have an MSA Fibre link to a host.
-

 **IMPORTANT:** If you encounter any problems during the firmware update process, stop and contact HP technical support. See “[HP technical support](#)” on page 9 for support contact information.

1. Schedule a maintenance window for the update.
2. Obtain the firmware files (.bin option) and save it to a temporary location on the host. Firmware updates are provided on the **Software, firmware & drivers** page of MSA websites:
[MSA 1000: http://www.hp.com/go/msa1000](http://www.hp.com/go/msa1000)
[MSA 1500: http://www.hp.com/go/msa1500cs](http://www.hp.com/go/msa1500cs)
3. Perform a *full* backup of the data on the array.
4. If the MSA has not been restarted in the last six months, power-cycle the array. This ensures that you are working with a fresh system before beginning the firmware update.

5. Open an emulator session to access the CLI.

6. Enter the following command:

```
download firmware offline
```

This command performs an update and does not automatically restart the MSA. Through this updating method, the MSA controller and fan modules can be updated. This method is supported for use in both single-controller and dual-controller configurations.


7. On the emulator window menu bar, select **Transfer > Send File**.
 - a. Click **Browse**, navigate to the directory in which you placed the firmware files, and then select the firmware file.
 - b. Expand the Protocol drop-down box, and then select **1K Xmodem**.
 - c. Click **Send**. A 1K Xmodem status window is displayed.
-

 **NOTE:** During the updating process, the following messages are displayed on the MSA controller LCD panel:

```
FIRMWARE FLASH STARTED
```

```
FIRMWARE FLASH DONE
```

8. Wait for a completion message to be displayed.
9. Restart the MSA by pressing the power/standby button on the front of the MSA. Newly downloaded firmware cannot be accessed until the MSA is restarted.

 **NOTE:** In dual-controller configurations, firmware on the two controllers is compared each time the MSA chassis is restarted. If the versions are mismatched, the system prompts to clone the firmware on the controller with the latest version over to the controller with the earlier version firmware. The following message is displayed on the LCD panel of the controller with the earlier firmware:


```
07 CLONE FIRMWARE ? '<' = NO, '>' = YES
```

Press the > button on the LCD panel to clone the firmware. During the cloning process, informational messages are displayed on the controller LCD panels. When the cloning process is complete, the just-updated controller automatically restarts.

10. Before resuming I/O access to the MSA, verify that the MSA and its storage arrays are online.

Disabling a controller for removal

In a dual-controller system, this command disables one of the controllers to prepare it for removal. When a controller is disabled, all resources being processed by that controller are automatically failed over to the remaining controller. After a controller has been successfully disabled, the LCD panel displays a message stating that it is safe for that controller to be removed.

 **NOTE:** This command is available only in dual-controller configurations.


Basic command

```
disable other_controller
-or-
disable this_controller
-or-
disable standby
```

Overriding the ACU lock

To prevent simultaneous use of more than one management interface, the system automatically places a lock on the MSA CLI whenever the Array Configuration Utility (ACU) or the Array Configuration Utility - Command Line Interface (ACU-CLI) is managing the MSA.

This command can disable the lock and allow the CLI to be used at the same time that the ACU or ACU-CLI is active.

 **CAUTION:** Turn off the ACU lock only under strict supervision. Multiple configuration sessions may lead to contradictory commands, unintended configuration changes, inappropriate actions, or a disrupted status.

Basic command

```
override aculock <on|off>
```

Enabling or disabling debug console logging

To allow additional system level messages to appear on the CLI console during failure events (such as hard drive, power supply, or fan module failures):

Basic command

```
set debug <on|off>
```

Host connection commands


Each time the MSA is powered on, all active HBA connections to the MSA are automatically detected and identified by their WWPN.

Before a host accesses the storage of the MSA, you must identify the operating system (host mode) of each connection. HP also recommends assigning a user-defined name to each connection, to make the identification and setup of each connection easier.

After connections are established, be sure to restrict access to the LUNs to specific hosts. The CLI uses an Access Control List (ACL) to enter the list of LUNs a host can access. See ["Access Control List commands"](#) on page 43 for more information about SSP and ACLs.

Each of the following commands is used to enter and manage the connections:

- [Adding a connection](#)
- [Changing the profile of a connection](#)
- [Changing the user-defined name of a connection](#)
- [Deleting the user-defined name of a connection](#)
- [Creating a new profile](#)
- [Moving to a different profile](#)
- [Changing the profile mode](#)

 **NOTE:** Use the `show connections` command to display information about each HBA connected to the MSA, including connection name, WWPN, and profile. See ["Show commands"](#) on page 19 for an example display.

Adding a connection

If the host is not yet connected to the MSA, but WWPN of the HBA is known, you can use this command to manually add, name, and identify the connection.

Basic command

```
add connection <ConnectionName> <wwpn=xxxxxxxx-xxxxxxxx> [profile=profile_name]
[offset=offset_value]
```

Command options

`ConnectionName`—the user-defined name to give the connection, up to 16 alphanumeric characters.

`wwpn=xxxxxxxx-xxxxxxxx`—the WWPN of the active HBA inside the host attached to the MSA.

The `show connections` command can be used to obtain the WWPN.

`profile=profile_name`—the platform of the host. Options include:

`Default`—is not operating-system specific and should not be used; use a valid pre-defined name.

`Windows`

`OpenVMS`

`Tru64`

`Linux`

`Solaris`

`Netware`

`HP`

`offset=offset_value`—(default: 0) the unit offset for assigning logical volumes.

Example command and response

```
CLI> add connection MSA-1 wwpn=12345678-12345678 profile=windows
```

```
Connection MSA-1 has been added successfully.
```

```
Profile Windows is set for the new connection.
```


Changing the profile of a connection

To change the operating-system profile associated with an existing connection (or to change the HBA of a connection):

 **NOTE:** The connection profile is sometimes referred to as the Host Mode.

Basic command

```
set connection <ConnectionName> [wwpn=xxxxxxxx-xxxxxxxx] [profile=profile_name]
[offset=offset_value]
```

Command options

ConnectionName—the name of the connection to modify.

wwpn=xxxxxxxx-xxxxxxxx—the WWPN of the connection to modify, using the WWPN of the HBA. The “show connections” can be used to obtain the WWPN.

profile=profile_name—the platform of the host. Options include:

Default—is not operating-system specific and should not be used; use a valid pre-defined name.

Windows

OpenVMS

Tru64

Linux

Solaris

Netware

HP

offset=offset_value—(default: 0) the unit offset for assigning logical volumes.

Example command and response

```
CLI> set connection MSA-1 profile=windows
```

The profile of connection MSA-1 is set to Windows successfully.

Changing the user-defined name of a connection

To change the user-defined name associated with a connection:

Basic command

```
rename connection <old_connection_name> <new_connection_name>
```

Command options

old_connection_name—the name of the connection that is to be changed.

new_connection_name—the new name to assign to the connection, up to 16 alphanumeric characters.

Example command and response

```
CLI> rename connection abc xyz
```

Connection(s) has been renamed successfully.

Deleting the user-defined name of a connection

To remove the user-defined name associated with a connection to a host:

Basic command

```
delete connection <connection_name>
```

Command options

`connection_name`—the nickname that was assigned to the HBA within the host.

Example command and response

```
CLI> delete connection MSA-1
```

Connection(s) has been deleted successfully.

Creating a new profile

This command creates a new host profile.

Basic command


```
add profile <profileName>
```

Command options

`profileName`—the name of a new profile.

Moving to a different profile

This command copies the profile settings of a valid, pre-defined profile into a different profile.

 **NOTE:** If you are migrating from active/passive to active/active firmware and did not set your profile (it is still set to default), you can use this command to copy the settings for a valid profile (such as Windows) into the default profile.

However, HP recommends using the `set connection` command to properly set the host connection. For details, see [“Changing the profile of a connection” on page 41](#).

Basic command

```
copy profile <sourceName> <destinationName>
```

Command options

`sourceName`—the name of an existing, valid profile whose settings you want to copy.

`destinationName`—the name of the profile (such as Default) that is importing the settings.

Pre-defined profiles include:

Default—is not operating-system specific and should not be used; use a valid pre-defined name.

Windows

OpenVMS

Tru64

Linux

Solaris

Netware

HP

Example command

```
CLI> copy profile Windows default
```

Changing the profile mode

This command changes a host profile mode based on the number of the mode that is displayed in the `show profile` command.

△ **CAUTION:** Use only under the advise of an authorized customer support technician.

Basic command

```
change mode <profileName> <hostModeNumber>
```

Command options

`profileName`—the name of an existing profile.

`hostModeNumber`—the number that is displayed next to the mode in the `show profile` command.

Access Control List commands

When multiple hosts access the storage of the MSA, it becomes necessary to restrict access to LUNs to specific hosts. The CLI uses an Access Control List (ACL) to enter the list of LUNs a host can access.

📋 **NOTE:** Even in the same OS environment, if multiple servers and HBAs have access to the same LUN, all of the HBAs must be of the same model.

Each of the following commands is used to set up and manage the ACL:

- [Viewing the ACL](#)
- [Adding to the ACL](#)
- [Deleting information from the ACL](#)

Each of these tasks is defined in the following sections.

📋 **NOTE:** Use the `show connections` command to display the connection name, defined profile type, and the WWPN of each HBA connected to the MSA.

The connection name or the WWPN is required when entering ACL information. See "[Show commands](#)" on page 19 for a sample display.

Viewing the ACL

To display the current ACL:

Basic command

```
show acl
```

Example command and response

```
CLI> show acl
```

```
ACL is enabled:
```

Connection	WWPN	Units
ABC	11111111-22222222	0,1,2
XYZ	33333333-44444444	3,4

Inaccessible Units: 5,6

Adding to the ACL

Two methods of entering LUN assignments are available:

- Adding to the ACL using the connection name
- Adding to the ACL using the WWPN

Basic command


```
add acl <connection=name> <unit=#>
-or
add acl <connection=wwpn=xxxxxxxx-xxxxxxxx> <unit=#>
```

Command options

connection=name—the name of the connection to grant access.

connection=wwpn=xxxxxxxx-xxxxxxxx—the WWPN of the connection to grant access.

unit=#—the LUN or range of LUNs to assign to the indicated host. Access to all units can be granted by entering all.

 **NOTE:** The ACL is automatically activated when the first entry is made.

Example command and response

```
CLI> add acl connection=wwpn=12345678-12345678 unit=2
```

Allowing 12345678-12345678 access to unit 2.

Deleting information from the ACL

After the ACL has been set up, access permissions for certain LUNs may need to be removed.

Two methods of removing access to previously assigned LUNs are available:

- Deleting information from the ACL using the connection name
- Deleting information from the ACL using the WWPN

Basic command


```
delete acl <connection=name> <unit=#>
-or
delete acl <connection=wwpn=xxxxxxxx-xxxxxxxx> <unit=#>
```

Command options

connection=name—the name of the connection for which you want to remove access.

connection=wwpn=xxxxxxxx-xxxxxxxx—the WWPN of the connection for which you want to remove access.

unit=#—the LUNs, or range of LUNs, to remove from the ACL of the indicated host. Access to all units can be removed by entering all.

 **NOTE:** If all entries in the ACL are being deleted, immediately after the last entry is deleted, all connected hosts have unlimited access to the storage.

Example command and response

```
CLI> delete acl wwpn=12345678-12345678 unit=1
```

Disallowing 12345678-12345678 access to unit 1.

A Storage overview

Arrays and logical drives

The capacity and performance of a single physical (hard) drive is adequate for home users. However, business users demand higher storage capacities, higher data transfer rates, and greater protection against data loss when drives fail.

Connecting extra physical drives (Figure 1) to a system increases the total storage capacity but has no effect on the efficiency of read/write (R/W) operations. Data can still be transferred to only one physical drive at a time.




Figure 1 Multiple physical drives (D1, D2, and D3) in a system

An array controller combines several physical drives into one or more virtual units called logical drives, which have superior performance, capacity, and/or fault-tolerant features than separate physical drives. The read/write heads of all included physical drives are active simultaneously, reducing the total time required for data transfer.




Figure 2 Multiple physical drives (D1, D2, and D3) configured into one logical drive (L1)

Because the read/write heads are active simultaneously, the same amount of data is written to each drive during any given time interval. Each unit of data is called a block, and adjacent blocks form a set of data stripes across all physical drives in that logical drive (Figure 3).




Figure 3 Data striping (S1-S4) and data blocks (B1-B12) on multiple physical drives (D1, D2, and D3)

For data in the logical drive to be readable, the data block sequence must be the same in every stripe. This sequencing process is performed by the array controller, which sends the data blocks to the drive write heads in the correct order.

A natural consequence of the striping process is that each physical drive in a given logical drive will contain the same amount of data. If one physical drive has a larger capacity than other physical drives in the same logical drive, the extra capacity is wasted, because it cannot be used by the logical drive.

The group of physical drives containing the logical drive is called a drive array, or array. Because all physical drives in an array are commonly configured into just one logical drive, the term array is often used as a synonym for logical drive. However, an array can contain several logical drives, each of a different size (Figure 4).




Figure 4 Two arrays (A1, A2) containing five logical drives (L1 through L5) spread across five physical drives (D1 through D5)

Each logical drive in an array is distributed across all of the physical drives within the array. A logical drive can also extend across more than one storage enclosure attached to the array system.

Drive failure, although rare, is potentially catastrophic. For example, in Figure 4, failure of any one physical drive in an array causes every logical drive in the array to suffer irretrievable data loss.

To protect against data loss due to physical drive failure, logical drives are usually configured with fault tolerance.

Fault-tolerance methods

To protect against data loss due to physical drive failure, logical drives are usually configured with fault tolerance. The following configuration types are available:

- RAID 0—Data striping only (no fault tolerance)
- RAID 1+0—Drive mirroring
- RAID 5—Distributed data guarding
- RAID 6 (ADG)—Advanced data guarding

For any configuration except RAID 0, further protection against data loss can be achieved by assigning a drive as an online spare. This drive contains no data and is connected to the same controller as the array. When any other physical drive in the array fails, the controller automatically rebuilds information data protection. (In the unlikely event that another drive in the array fails while data is being rewritten to the spare, the logical drive will still fail.)

A spare is assigned to an array and is automatically assigned to all logical drives in the same array. You do not need to assign a separate spare to each array; you can configure one hard drive to be the spare for several arrays.

RAID 0—No fault tolerance

A RAID 0 configuration (Figure 3) provides no protection against data loss when a drive fails. However, it is useful for rapid storage of large amounts of non-critical data (for printing or image editing, for example), or when cost is the most important consideration.

Table 3 RAID 0 features

Advantages	Disadvantages
Highest write performance of all RAID methods.	All data on the logical drive is lost if a physical drive fails.
Lowest cost per unit of stored data of all RAID methods.	Cannot use an online spare.
All drive capacity is used to store data (none is needed for fault tolerance).	Can only preserve data by backing it up to external drives.

RAID 1+0—Drive mirroring

In a RAID 1+0 configuration, data on a physical hard drive is duplicated to a second drive.

NOTE: When only two hard drives are included in the array, this fault-tolerance method is called RAID 1. When more than two hard drives are included in the array, this fault-tolerance method is called RAID 1+0. RAID 1 is not supported on the MSA1510i storage system.




Figure 5 RAID 1 array, with two physical hard drives (D1 and D2)

When the array has more than two physical drives, drives are mirrored in pairs (Figure 6).




Figure 6 RAID 1+0 array, with eight physical hard drives (D1 through D8)

In each mirrored pair, the physical drive that is not busy answering other requests answers any read requests that are sent to the array. (This behavior is called load balancing.) If a physical drive fails, the remaining drive in the mirrored pair can still provide all the necessary data. Several drives in the array can fail without incurring data loss, as long as no two failed drives belong to the same mirrored pair.

RAID 1+0 is useful when high performance and data protection are more important than the cost of physical drives.

Table 4 RAID 1, RAID 1+0 features

Advantages	Disadvantages
Highest read and write performance of any fault-tolerant configuration.	Expensive (half of the drives are used for fault tolerance).
No loss of data as long as no failed drive is mirrored to another failed drive.	Only half of total drive capacity usable for data storage.

RAID 5—Distributed data guarding

In this method, a block of parity data is calculated for each stripe from the data that is in all other blocks within that stripe. The blocks of parity data are distributed across every physical drive within the logical drive (Figure 7). When a physical drive fails, data that was on the failed drive can be calculated from the data on the remaining drives and the parity data. This recovered data is written to the assigned spare or to a replacement drive in a process called a rebuild.




Figure 7 RAID 5 array, with three physical hard drives (D1, D2, and D3) showing distributed parity information (Px,y)

This configuration is useful when cost, performance, and data availability are equally important.

Table 5 RAID 5 features

Advantages	Disadvantages
Highest read performance.	Relatively low write performance.
No loss of data if one physical drive fails.	Loss of data if a second drive fails before data from the first failed drive is rebuilt.
More usable drive capacity than RAID 1+0, because parity information requires the storage space equivalent to one physical drive.	

RAID 6—Advanced data guarding

RAID 6 (also called RAID ADG) is similar to RAID 5, because both methods generate and store parity information to protect against data loss caused by drive failure. With RAID 6, however, two different sets of parity data are distributed across the physical drives, allowing data to be preserved even if two drives fail. Each set of parity data uses up a capacity equivalent to that of one of the constituent drives, as shown in Figure 8.




Figure 8 RAID 6 array, with four physical hard drives (D1, D2, D3, and D4) showing distributed parity information (Px,y)(Qx,y)

This method is most useful when data loss is unacceptable, but cost is also an important factor. The probability that data loss will occur when arrays are configured with RAID 6 is less than when they are configured with RAID 5.

Table 6 RAID 6 features

Advantages	Disadvantages
High read performance.	Relatively low write performance (lower than RAID 5), because of the need to create two sets of parity data.
High data availability—Any two drives can fail without loss of critical data.	
More drive capacity is usable than with RAID 1+0—Parity information requires only the storage equivalent to two physical drives.	

Comparison of RAID methods

Table 7 summarizes important features of the different RAID levels.

Table 7 Summary of RAID methods

	RAID 0	RAID 1+0	RAID 5	RAID 6
Alternative name	Striping	Mirroring	Distributed Data Guarding (DDG)	Advanced Data Guarding (ADG)
Usable drive space*	100%	50%	67% to 93%	50% to 96%
Usable drive space formula	n	n/2	(n-1)/n	(n-2)/n
Minimum number of physical drives	1	2	3	4
Tolerates physical drive failure?	No	Yes	Yes	Yes
Tolerates simultaneous failure of more than one physical drive?	No	Only if no two failed drives are in a mirrored pair	No	Yes
Read performance	High	High	High	High
Write performance	High	Medium	Low	Low
Relative cost	Low	High	Medium	Medium
<p>*Values for usable drive space are calculated with these assumptions:</p> <ul style="list-style-type: none"> • All physical drives in the array have the same capacity. • Online spares are not used. • No more than 14 physical drives are used per array for RAID 5. • No more than 56 drives are used with RAID 6. 				

Choosing a RAID level

Use Table 8 to help you determine the best RAID level for your environment.

Table 8 Choosing a RAID level

Most important characteristic	Also important	Suggested RAID level
Fault tolerance	Cost effectiveness	RAID 6
	I/O performance	RAID 1+0
Cost effectiveness	Fault tolerance	RAID 6*
	I/O performance	RAID 5 (RAID 0 if fault tolerance is not required)
I/O performance	Cost effectiveness	RAID 5 (RAID 0 if fault tolerance is not required)
	Fault tolerance	RAID 1+0

Index

A

Access Control Lists See ACL

ACL

- adding to with the CLI 44
- commands 43
- deleting from, with the CLI 44
- viewing, with the CLI 43

ADD ACL command 44

ADD CONNECTION command 40

ADD PROFILE command 42

ADD UNIT command 26

array controller configuration, with the CLI 35

arrays and logical drives 45

audience 7

authorized reseller, HP 9

C

cache, enabling/disabling per LUN with the CLI 32

CHANGE MODE command 43

CLI

- ACL commands 43
- ACL, adding to 44
- ACL, deleting from 44
- ACL, viewing 43
- ACU, overriding lockout 39
- array controller configuration commands 35
- array, expanding 30
- command option, defined 12
- command syntax 12
- connections, adding 40
- connections, changing profiles of 41
- connections, changing the name of 41
- connections, deleting names of 42
- connections, viewing 40, 43
- controller ID, setting of 36
- debug logging 39
- display commands 19
- firmware, updating of 37
- global settings 35
- hard addressing, setting of 36
- hard drives, locating 25
- help command, described 17
- Hyper Terminal, setting up 14
- inter-controller link, defined 12
- LUN management commands 25
- LUN names, assigning 28
- LUN, cache, enabling/disabling 32
- LUN, creating 26
- LUN, extending 31
- overview of 11
- profile, adding new 42
- profile, changing 42
- profile, changing mode of 43

prompt, changing of 37

serial cable requirements 14

serial connection, setup 14

Server Connection Commands 40

setup 14

special keystrokes 11

command line interface, see CLI

commands

ADD ACL 44

ADD CONNECTION 40

ADD PROFILE 42

ADD UNIT 26

CHANGE MODE 43

COPY PROFILE 42

DELETE ACL 44

DELETE CONNECTION 42

DOWNLOAD FIRMWARE 37

EXPAND UNIT 30

EXTEND UNIT 31

LOCATE 25

OVERRIDE ACULOCK 39

RENAME CONNECTION 41

SET CONNECTION 41

SET DEBUG 39

SET GLOBALS 35

SET OTHER_CONTROLLER 36

SET PROMPT 37

SET THIS_CONTROLLER 36

SET UNIT 32

SET UNIT_ID 28

SHOW ACL 43

connections

adding, with the CLI 40

changing profiles of, with the CLI 41

changing the name of, with the CLI 41

deleting names of, with the CLI 42

viewing, with the CLI 40, 43

conventions

document 7

text symbols 8

COPY PROFILE command 42

D

DELETE ACL command 44

DELETE CONNECTION command 42

document

conventions 7

related documentation 7

documentation, HP website 7

DOWNLOAD FIRMWARE command 37

E

EXPAND UNIT command 30

EXTEND UNIT command [31](#)

F

fault tolerance methods [46](#)
flashing LEDs, with the CLI [25](#)

G

global controller settings, changing with the CLI [35](#)

H

hard addressing, setting [36](#)
hard drives, locating with the CLI [25](#)
help, obtaining [9](#)

HP

- authorized reseller [9](#)
- storage website [9](#)
- Subscriber's choice website [9](#)
- technical support [9](#)

Hyper Terminal, setting up [14](#)

I

inter-controller link, defined [12](#)

L

LOCATE command [25](#)
logical drives and arrays [45](#)

LUN

- creating with the CLI [26](#)
- extending with the CLI [31](#)
- names, assigning with the CLI [28](#)

O

OVERRIDE ACULOCK command [39](#)

R

RAID

- choosing a level [50](#)
- comparing methods [50](#)

RAID 0 configuration [47](#)

RAID 1+0 configuration [47](#)

RAID 5 configuration [48](#)

RAID 6 configuration [48](#)

related documentation [7](#)

RENAME CONNECTION command [41](#)

S

serial connection, setting up [14](#)

SET CONNECTION command [41](#)

SET DEBUG command [39](#)

SET GLOBALS command [35](#)

SET OTHER_CONTROLLER command [36](#)

SET PROMPT command [37](#)

SET THIS_CONTROLLER command [36](#)

SET UNIT command [32](#)

SET UNIT_ID command [28](#)

SHOW ACL command [43](#)

storage overview [45](#)

Subscriber's choice, HP [9](#)

symbols in text [8](#)

T

technical support, HP [9](#)

text symbols [8](#)

W

websites

- HP documentation [7](#)

- HP storage [9](#)

- HP Subscriber's choice [9](#)