





Patch Panel Ethernet Connections (for BL20p series)



Patch Panel/Patch Panel 2 Ethernet Connections
for ProLiant BL20p series blades

Item	Original Enclosure	Updated Enclosure
B1	iLO NIC, server 1	Not used on G1,G2 Data NIC, server 1(G3)
B2	Data NIC, server 1	Data NIC, server 1
A1	Data NIC*, server 1	Data NIC*, server 1
A2	Data NIC, server 1	Data NIC, server 1

**This is the default enabled PXE NIC. Using the ROM setup utility on the server, any other data NIC may be PXE enabled.*