

NBX100 OH Pri


Main AA

Opt.1 KY HG

KY Office
HG 4954

Opt.2 OH HG

OH Office
HG 5955



Directly
To HG 5955
By Passing the AA



KY Office
HG 4954
Ext's 5210 & 5242


Ext. 5242 90% of
the time it's the
only one used.

Ext. 5210 Used by
other staff when they
get flooded with calls.

If call is not answered during
business hours it should route
directly to VM on Ext. 5210 via
*25210 configured in HG 5954

Configure button on Ext. 5210 Preferable
Ext. 5242 when lit will FWD all calls back
to OH Main Office HG 5955

T1
DATA



NBX100 KY

