

hp 9000 rp3410 and rp3440 Server Errata: Important Information about your HP Server


Important Notes

The latest versions of server documentation and User Guides for the hp 9000 rp3410 and rp3440 Server can be found at <http://docs.hp.com>.

10/100 base-T Ethernet LAN Connector

Documentation and User Guides for the hp 9000 rp3410 and rp3440 Server erroneously report the presence of a 10/100 base-T Ethernet connector on the rear panel of the Server. This connector is not present on commercially available 9000 rp3410 and rp3440 Servers. See Figure 1.

Figure 1. Rear Panel of hp 9000 rp3410/rp3440 Server



Do Not Use Serial Port A (Console) and Serial Port B Connectors

Documentation and Guides for the hp 9000 rp4440 Server erroneously describe the Serial Port A and B connectors as functional and available for use. These connectors are for factory use only.

CPU Install Kit Part Number

The part number for the CPU Install Kit (required for CPU removal and installation) is stated incorrectly in some hp 9000 rp34xx Server documentation. The correct HP P/N for this kit is 5069-5441.

