

## SmartStart CD Supported Servers

[HP ProLiant Bladesystem Server Support](#)

[HP ProLiant DL Server Support](#)

[HP ProLiant ML Server Support](#)

[Retired HP ProLiant Bladesystem Servers](#)

[Retired HP ProLiant DL Servers](#)

[Retired HP ProLiant ML Servers](#)

[Retired HP ProLiant and Prosignia Servers](#)

## HP ProLiant Bladesystem Server Support

This matrix reflects servers that are currently shipping.

	ProLiant BL20p G3	ProLiant BL25p	ProLiant BL35p	ProLiant BL45p
<b>SmartStart 7.40</b>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>
<b>SmartStart 7.30</b>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>
<b>SmartStart 7.20</b>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>
<b>SmartStart 7.10</b>				
<b>SmartStart 7.00</b>				
<b>SmartStart 6.xx</b>				

To learn more about the current shipping ML/DL and Blade platforms please visit:

<http://h18004.www1.hp.com/products/servers/platforms/index.html>

For support software downloads please visit:

[www.hp.com/go/support](http://www.hp.com/go/support)

For the ProLiant Supported OS Matrix please visit:

[www.hp.com/go/supportos](http://www.hp.com/go/supportos)



Supported<sup>1</sup>

Not supported by the specified version of SmartStart.

<sup>1</sup> Supported indicates:

- an Assisted Path OS Installation is supported on the specified server (when the OS is supported on the server. Refer to the ProLiant OS Support Matrix).
- Server maintenance is available for the specified server.

Last Updated:

Wednesday, December 21, 2005

## HP ProLiant DL Server Support

This matrix reflects servers that are currently shipping.

	ProLiant DL320 G3	ProLiant DL320 G4	ProLiant DL360 G4	ProLiant DL360 G4p	ProLiant DL380 G4	ProLiant DL385	ProLiant DL560	ProLiant DL580 G2	ProLiant DL580 G3	ProLiant DL585	ProLiant DL740	ProLiant DL760 G2	ProLiant DL380 G4 Packaged Cluster
<b>SmartStart 7.40</b>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>
<b>SmartStart 7.30</b>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>
<b>SmartStart 7.20</b>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>
<b>SmartStart 7.10</b>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>
<b>SmartStart 7.00</b>						<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>			<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>		
<b>SmartStart 6.40</b>						<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>			<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>		
<b>SmartStart 6.30</b>						<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>			<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>		
<b>SmartStart 6.20</b>						<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>			<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>		
<b>SmartStart 6.10</b>							<input checked="" type="checkbox"/>						
<b>SmartStart 6.00</b>							<input checked="" type="checkbox"/>						
<b>SmartStart 5.50</b>							<input checked="" type="checkbox"/>						

To learn more about the current shipping ML/DL and Blade platforms please visit:

<http://h18004.www1.hp.com/products/servers/platforms/index.html>

For support software downloads please visit:

[www.hp.com/go/support](http://www.hp.com/go/support)

For the ProLiant Supported OS Matrix please visit:

[www.hp.com/go/supportos](http://www.hp.com/go/supportos)

- Supported<sup>1</sup>
- Not supported by the specified version of SmartStart.
- SmartStart supports deployment of the server only. It does not deploy the full cluster solution. Click here to learn more about the HP Clustering Solution.

<sup>1</sup> Supported indicates:

- an Assisted Path OS Installation is supported on the specified server (when the OS is supported on the server. Refer to the ProLiant OS Support Matrix).
- Server maintenance is available for the specified server.

## HP ProLiant ML Server Support

This matrix reflects servers that are currently shipping.

	ProLiant ML310 G2	ProLiant ML310 G3	ProLiant ML350 G4	ProLiant ML350 G4p	ProLiant ML370 G4	ProLiant ML570 G2	ProLiant ML570 G3
<b>SmartStart 7.40</b>	☑	☑	☑	☑	☑	☑	☑
<b>SmartStart 7.30</b>	☑	☐	☑	☑	☑	☑	☑
<b>SmartStart 7.20</b>	☑	☐	☑	☐	☑	☑	☐
<b>SmartStart 7.10</b>	☐	☑	☐	☐	☑	☑	☑
<b>SmartStart 7.00</b>	☐	☐	☐	☐	☐	☑	☐
<b>SmartStart 6.40</b>	☐	☐	☐	☐	☐	☑	☐
<b>SmartStart 6.30</b>	☐	☐	☐	☐	☐	☑	☐
<b>SmartStart 6.20</b>	☐	☐	☐	☐	☐	☑	☐
<b>SmartStart 6.10</b>	☐	☐	☐	☐	☐	☑	☐
<b>SmartStart 6.00</b>	☐	☐	☐	☐	☐	☑	☐
<b>SmartStart 5.50</b>	☐	☐	☐	☐	☐	☐	☐

To learn more about the current shipping ML/DL and Blade platforms please visit:  
<http://h18004.www1.hp.com/products/servers/platforms/index.html>

For support software downloads please visit:  
[www.hp.com/go/support](http://www.hp.com/go/support)

For the ProLiant Supported OS Matrix please visit:  
[www.hp.com/go/supportos](http://www.hp.com/go/supportos)

☑ Supported<sup>1</sup>  
 ☐ Not supported by the specified version of S

- <sup>1</sup> Supported indicates:
- an Assisted Path OS Installation is supported on the specified server (when the OS is supported on the server. Refer to the ProLiant OS Support Matrix).
  - Server maintenance is available for the specified server.

**Last Updated:**  
 Wednesday, December 21, 2005

## SmartStart CD Server Support Matrix

### Retired HP Bladesystem Servers

This page reflects retired Blade Servers that are no longer shipping.

	ProLiant BL10e	ProLiant BL20p	ProLiant BL20p G2	ProLiant BL10e G2	ProLiant BL30p	ProLiant BL40p
<b>SmartStart 7.40</b>	☑	☑	☑	☑	☑	☑
<b>SmartStart 7.30</b>	☑	☑	☑	☑	☑	☑
<b>SmartStart 7.20</b>	☑	☑	☑	☑	☑	☑
<b>SmartStart 7.10</b>	☑	☑	☑	☑	☑	☑
<b>SmartStart 7.00</b>	☑	☑	☑	☑	☑	☑
<b>SmartStart 6.40</b>	☑	☑	☑	☑	☑	☑
<b>SmartStart 6.30</b>	☑	☑	☑	☑	☑	☑
<b>SmartStart 6.20</b>	☑	☑	☑	☑	☑	☑
<b>SmartStart 5.50</b>	☑	☑	☑	☑	☑	☑

To learn more about the current shipping ML/DL and Blade platforms please visit:

<http://h18004.www1.hp.com/products/servers/platforms/index.html>

For support software downloads please visit:

[www.hp.com/go/support](http://www.hp.com/go/support)

For the ProLiant Supported OS Matrix please visit:

[www.hp.com/go/supportos](http://www.hp.com/go/supportos)

Blade servers utilize the software contained in the [ProLiant Support Packs \(PSPs\)](#)<sup>2</sup>.

Not supported by SmartStart.

Supported<sup>1,4</sup>

<sup>1</sup> No Assisted Path OS installation from SmartStart 6.xx or 7.xx to these servers. Obtain the latest software from either of the following locations:

- the Software and Drivers download facility by inserting and browsing the SmartStart 6.xx CD from any workstation.
- the online HP Software and Drivers download site.

For server deployment on these systems use SmartStart 5.50, available for order or free download at:

[www.hp.com/servers/smartstart](http://www.hp.com/servers/smartstart).

<sup>2</sup> Blade servers utilize [PSPs](#). PSPs are available on the SmartStart CD. For server deployment use SmartStart 5.50, available for order or download at: [www.hp.com/servers/smartstart](http://www.hp.com/servers/smartstart), [Rapid Deployment Pack](#), [SmartStart Scripting Toolkit](#) and [SmartStart 7.xx](#) deploy BladeSystem Servers. SmartStart 7.00 or later can now deploy the ProLiant BL20P and BL40P G2 servers, using the I/O port with an attached USB CD-ROM device. SmartStart is not delivered with these servers.

<sup>4</sup> Supported indicates:

- an Assisted Path OS Installation is supported on the specified server (when the OS is supported on the server. Refer to the [ProLiant OS Support Matrix](#)).
- Software updates are available for the specified server.
- Server maintenance is available for the specified server.

Last Updated:

Wednesday, December 21, 2005

**SmartStart CD  
Server Support Matrix**

**Retired HP ProLiant DL Servers**

This page reflects retired DL products that are no longer shipping.

	ProLiant DL320	ProLiant DL320 G2	ProLiant DL360 (550MHz-1.26GHz)	ProLiant DL360 G2	ProLiant DL360 G3	ProLiant DL380 (667MHz-1GHz)	ProLiant DL380 G2	ProLiant DL380 G3	ProLiant DL580	ProLiant DL590/64	ProLiant DL760	ProLiant DL380 G2 Packaged Cluster	ProLiant DL380 G3 Packaged Cluster - MS/LS20
SmartStart 7.40	☑	☑	☑	☑	☑	☑	☑	☑	☑	☑	☑	☑	☑
SmartStart 7.30	☑	☑	☑	☑	☑	☑	☑	☑	☑	☑	☑	☑	☑
SmartStart 7.20	☑	☑	☑	☑	☑	☑	☑	☑	☑	☑	☑	☑	☑
SmartStart 7.10	☑	☑	☑	☑	☑	☑	☑	☑	☑	☑	☑	☑	☑
SmartStart 7.00	☑	☑	☑	☑	☑	☑	☑	☑	☑	☑	☑	☑	☑
SmartStart 6.40	☑	☑	☑	☑	☑	☑	☑	☑	☑	☑	☑	☑	☑
SmartStart 6.30	☑	☑	☑	☑	☑	☑	☑	☑	☑	☑	☑	☑	☑
SmartStart 6.20	☑	☑	☑	☑	☑	☑	☑	☑	☑	☑	☑	☑	☑
SmartStart 6.10	☑	☑	☑	☑	☑	☑	☑	☑	☑	☑	☑	☑	☑
SmartStart 6.00	☑	☑	☑	☑	☑	☑	☑	☑	☑	☑	☑	☑	☑
SmartStart 5.50	☑	☑	☑	☑	☑	☑	☑	☑	☑	☑	☑	☑	☑

To learn more about the current shipping ML/DL and Blade platforms please visit:

<http://h18004.www1.hp.com/products/servers/platforms/index.html>

For support software downloads please visit:

[www.hp.com/go/support](http://www.hp.com/go/support)

For the ProLiant Supported OS Matrix please visit:

[www.hp.com/go/supporttos](http://www.hp.com/go/supporttos)

- ☑ Supported by SmartStart 5.50 and the following ProLiant Support Packs (PSPs):  
 -ProLiant Support Pack for Microsoft Windows Server 2003  
 -ProLiant Support Pack for Microsoft Windows 2000  
 -ProLiant Support Pack for Microsoft Windows NT 4.0  
 -ProLiant Support Pack for Novell NetWare  
 -ProLiant Support Pack for Linux
- ☑ Supported by SmartStart 5.50 and the following PSPs:<sup>1</sup>  
 -ProLiant Support Pack for Microsoft Windows Server 2003  
 -ProLiant Support Pack for Microsoft Windows 2000  
 -ProLiant Support Pack for Microsoft Windows NT 4.0  
 -ProLiant Support Pack for Novell NetWare
- ☑ SmartStart supports deployment of the server only. It does not deploy the full cluster solution. Click here to learn more about the [HP Clustering Solution](#).
- ☐ Not supported by SmartStart. Refer to the Compaq ProLiant DL590/64 Server Support Software Release 1.0 for support.
- ☑ Supported<sup>1,4</sup>

<sup>1</sup> No Assisted Path OS installation from SmartStart 6.xx or 7.xx to these servers. Obtain the latest software from either of the following locations:

- the Software and Drivers download facility by inserting and browsing the SmartStart 6.xx CD from any workstation.
- the online HP Software and Drivers download site.

For server deployment on these systems use SmartStart 5.50, available for order or free download at: [www.hp.com/servers/smartstart](http://www.hp.com/servers/smartstart).

<sup>4</sup> Supported indicates:

- an Assisted Path OS Installation is supported on the specified server (when the OS is supported on the server. Refer to the [ProLiant OS Support Matrix](#)).
- Software updates are available for the specified server.
- Server maintenance is available for the specified server.

Last Updated:

Wednesday, December 21, 2005

## SmartStart CD Server Support Matrix

### Retired HP ProLiant ML Servers

This page reflects retired ML products that are no longer shipping.

	ProLiant ML310	ProLiant ML330 (667MHz-1GHz)	ProLiant ML330 G2	ProLiant ML330 G3	ProLiant ML330e	ProLiant ML350 (667MHz-1GHz)	ProLiant ML350 G2	ProLiant ML350 G3	ProLiant ML370 (667MHz-1GHz)	ProLiant ML370 G2	ProLiant ML370 G3	ProLiant ML530	ProLiant ML530 G2	ProLiant ML570	ProLiant ML750
<b>SmartStart 7.40</b>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>
<b>SmartStart 7.30</b>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>
<b>SmartStart 7.20</b>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>
<b>SmartStart 7.10</b>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>
<b>SmartStart 7.00</b>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>
<b>SmartStart 6.40</b>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>
<b>SmartStart 6.30</b>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>
<b>SmartStart 6.20</b>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>
<b>SmartStart 5.50</b>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>

To learn more about the current shipping ML/DL and Blade platforms please visit:

<http://h18004.www1.hp.com/products/servers/platforms/index.html>

For support software downloads please visit:

[www.hp.com/go/support](http://www.hp.com/go/support)

For the ProLiant Supported OS Matrix please visit:

[www.hp.com/go/supportos](http://www.hp.com/go/supportos)



Supported by SmartStart 5.50 and the following ProLiant Support Packs (PSPs).<sup>1</sup>

- ProLiant Support Pack for Microsoft Windows Server 2003
- ProLiant Support Pack for Microsoft Windows 2000
- ProLiant Support Pack for Microsoft Windows NT 4.0
- ProLiant Support Pack for Novell NetWare
- ProLiant Support Pack for Linux



Not supported by SmartStart.



Supported<sup>1,4</sup>

<sup>1</sup> No Assisted Path OS installation from SmartStart 6.xx or 7.xx to these servers. Obtain the latest software from either of the following locations:

- the Software and Drivers download facility by inserting and browsing the SmartStart 6.xx CD from any workstation.
- the online HP Software and Drivers download site.

For server deployment on these systems use SmartStart 5.50, available for order or free download at: [www.hp.com/servers/smartstart](http://www.hp.com/servers/smartstart).

<sup>4</sup> Supported indicates:

- an Assisted Path OS Installation is supported on the specified server (when the OS is supported on the server. Refer to the [ProLiant OS Support Matrix](#)).
- Software updates are available for the specified server.
- Server maintenance is available for the specified server.

## SmartStart CD Server Support Matrix

### Retired HP ProLiant & Prosignia Servers

This page reflects retired products that are **no longer shipping**.

	Prosignia 720	Prosignia 740	ProLiant 400 (P1I & P1II)	ProLiant 800 (P1I & P1II)	ProLiant 1600 (P1I & P1II)	ProLiant 1850R (P1I & P1II)	ProLiant 3000 (P1I & P1II)	ProLiant 5500 (P1I & P1II)	ProLiant 6000 (P1I & P1II)	ProLiant 6400 (P1II)	ProLiant 6500 (P1I & P1II)	ProLiant 7000 (P1I & P1II)	ProLiant 8000	ProLiant 8500	ProLiant CL1850	ProLiant CL380
<b>SmartStart 7.40</b>	☑	☑	☑	☑	☑	☑	☑	☑	☑	☑	☑	☑	☑	☑	☑	☑
<b>SmartStart 7.30</b>	☑	☑	☑	☑	☑	☑	☑	☑	☑	☑	☑	☑	☑	☑	☑	☑
<b>SmartStart 7.20</b>	☑	☑	☑	☑	☑	☑	☑	☑	☑	☑	☑	☑	☑	☑	☑	☑
<b>SmartStart 7.10</b>	☑	☑	☑	☑	☑	☑	☑	☑	☑	☑	☑	☑	☑	☑	☑	☑
<b>SmartStart 7.00</b>	☑	☑	☑	☑	☑	☑	☑	☑	☑	☑	☑	☑	☑	☑	☑	☑
<b>SmartStart 6.xx</b>	☑	☑	☑	☑	☑	☑	☑	☑	☑	☑	☑	☑	☑	☑	☑	☑
<b>SmartStart 5.50</b>	☑	☑	☑	☑	☑	☑	☑	☑	☑	☑	☑	☑	☑	☑	☑	☑

To learn more about the current shipping ML/DL and Blade platforms please visit:  
<http://h18004.www1.hp.com/products/servers/platforms/index.l>

For support software downloads please visit:  
[www.hp.com/go/support](http://www.hp.com/go/support)

For the ProLiant Supported OS Matrix please visit:  
[www.hp.com/go/supportos](http://www.hp.com/go/supportos)

☑ Supported by SmartStart 5.50 and the following PSPs<sup>1</sup>  
 -ProLiant Support Pack for Microsoft Windows Server 2003  
 -ProLiant Support Pack for Microsoft Windows 2000  
 -ProLiant Support Pack for Microsoft Windows NT 4.0  
 -ProLiant Support Pack for Novell NetWare

☑ Supported by SmartStart 5.50 and the following PSPs<sup>1</sup>  
 -ProLiant Support Pack for Microsoft Windows Server 2003<sup>3</sup>  
 -ProLiant Support Pack for Microsoft Windows 2000  
 -ProLiant Support Pack for Microsoft Windows NT 4.0  
 -ProLiant Support Pack for Novell NetWare

☐ Not supported by SmartStart. Refer to the Compaq ProLiant DL590/64 Server Support Software Release 1.0 for support.

☑ Supported<sup>1,4</sup>

☑ These retired servers are supported by SmartStart 5.50 and the following PSPs.<sup>1,2</sup>  
 -ProLiant Support Pack for Microsoft Windows 2000  
 -ProLiant Support Pack for Microsoft Windows NT 4.0  
 -ProLiant Support Pack for Novell NetWare

☑ SmartStart supports deployment of the server only. It does not deploy the full cluster solution. Click here to learn more about the [HP Clustering Solution](#).

<sup>1</sup> No Assisted Path OS installation from SmartStart 6.xx or 7.xx to these servers. Obtain the latest software from either of the following locations:  
 -the Software and Drivers download facility by inserting and browsing the SmartStart 6.xx CD from any workstation.  
 -the online HP Software and Drivers download site.  
 For server deployment on these systems use SmartStart 5.50, available for order or free download at: [www.hp.com/servers/smartstart](http://www.hp.com/servers/smartstart)

<sup>3</sup> Only the Pentium III Xeon Processor version of these products are supported by the ProLiant Support Pack for Microsoft Windows Server 2003.

<sup>4</sup> Supported indicates:  
 - an Assisted Path OS Installation is supported on the specified server (when the OS is supported on the server. Refer to the [ProLiant OS Support Matrix](#)).  
 - Software updates are available for the specified server.  
 - Server maintenance is available for the specified server.