
## HP ProCurve – how to re-flash the switch software through Boot ROM

## **CUSTOMER VIEWABLE**


- 1. If you did not receive the new software or download link from the Technical Support, download the latest version from <a href="http://h10144.www1.hp.com/customercare/support/software/index.htm">http://h10144.www1.hp.com/customercare/support/software/index.htm</a>
- 2. Power up the switch
- 3. Connect the console cable between the switch and your workstation.
- 4. Open a console connection to the switch using Tera Term Pro http://en.sourceforge.jp/projects/ttssh2/downloads/48772/teraterm-4.67.exe/



Do not change the connection settings.

Last updated: 08.09.2010 1/4

## 5. Open the console session log from File / Open




Last updated: 08.09.2010 2/4

- 6. Restart the switch to Boot ROM mode:
  - Press Reset and Clear simultaneously
  - Release Reset Self Test LED starts to blink
  - Wait until Self Test is no longer blinking but is burning steady, and release Clear
- 7. You will see this command prompt:

Press 'h' for Help

=>


- 8. Type 'do' and press Enter. This will prepare the switch to receive a new software via XMODEM protocol
- 9. On Tera Term Pro start the XMODEM send from File / Transfer / XMODEM / Send
- 10. Browse to the correct directory, choose the software file and click Open



- 11. When the SW has been uploaded, restart the switch by pressing Reset button
- 12. When the switch is running, give on the command line command 'show tech all'

Last updated: 08.09.2010 3/4

13. When the command output has finished, close the log from the separate log control window



14. Send the log to us for analysis.