

Flash Size : 128MB  
CPLD Version : 002  
PCB Version : Ver.B  
Mac Address : 4001C67AA1C0

Press Ctrl-B to enter Extended Boot menu...0  
Starting to get the main application file--flash:/S2900-CMW520-R1101P09.bin!...  
.....  
The main application file is self-decompressing.....  
.....  
.....Done!  
System is starting...  
Startup configuration file does not exist.  
User interface aux0 is available.

Press ENTER to get started.

Login authentication

Username:admin  
Password:  
<3Com Baseline Switch>  
#Apr 26 12:03:27:202 2000 3Com Baseline Switch SHELL/4/LOGIN:  
Trap 1.3.6.1.4.1.43.45.1.10.2.2.1.1.3.0.1<h3cLogIn>:admin login from Console  
%Apr 26 12:03:27:371 2000 3Com Baseline Switch SHELL/4/LOGIN: admin login from a  
ux0?

User view commands:  
initialize Delete the startup configuration file and reboot system  
ipsetup Specify the IP address of the VLAN interface 1  
password Specify password of local user  
ping Ping function  
quit Exit from current command view  
reboot Reboot system  
summary Display summary information of the device.  
upgrade Upgrade the system boot file or the Boot ROM program

<3Com Baseline Switch>initialize  
The startup configuration file will be deleted and the system will be rebooted.  
Continue? [Y/N]:y  
#Apr 26 12:03:57:851 2000 3Com Baseline Switch DEV/1/REBOOT:  
Reboot device by command.  
%Apr 26 12:03:57:961 2000 3Com Baseline Switch DEV/4/SYSTEM REBOOT:  
System is rebooting now.

Starting.....

```
*****  
*                                                                 *  
*           3COM 2952-SFP Plus BOOTROM, Version 119           *  
*                                                                 *  
*****  
Creation Date       : Feb  3 2010  
CPU L1 Cache       : 32KB  
CPU Clock Speed    : 333MHz  
Memory Size        : 128MB  
Flash Size         : 128MB  
CPLD Version       : 002  
PCB Version        : Ver.B  
Mac Address        : 4001C67AA1C0
```

Press Ctrl-B to enter Extended Boot menu...0  
Please input BootRom password:

BOOT MENU

1. Download application file to flash
2. Select application file to boot
3. Display all files in flash
4. Delete file from flash

5. Modify BootRom password
6. Enter BootRom upgrade menu
7. Skip current system configuration
8. Set BootRom password recovery
9. Set switch startup mode
0. Reboot

Enter your choice(0-9): 6

1. Update full BootRom
2. Update extended BootRom
3. Update basic BootRom
0. Return to boot menu

Enter your choice(0-3): 1

1. Set TFTP protocol parameters
2. Set FTP protocol parameters
3. Set XMODEM protocol parameters
0. Return to boot menu

Enter your choice(0-3): 3

Please select your download baudrate:

1. 9600
2. 19200
- 3.\* 38400
4. 57600
5. 115200
0. Return to boot menu

Enter your choice(0-5): 3

Download baudrate is 38400 bps

Please change the terminal's baudrate to 38400 bps and select XMODEM protocol

Press enter key when ready

Now please start transfer file with XMODEM protocol

If you want to exit, Press <Ctrl+X>

Loading ...CCCCCCCCCBB0BB0

Failed!

Please change the terminal's baudrate to 38400 bps, press ENTER when ready.

Press enter key when ready

1. Update full BootRom
2. Update extended BootRom
3. Update basic BootRom
0. Return to boot menu

Enter your choice(0-3): 1

1. Set TFTP protocol parameters
2. Set FTP protocol parameters
3. Set XMODEM protocol parameters
0. Return to boot menu

Enter your choice(0-3): 3

Please select your download baudrate:

1. 9600
2. 19200
- 3.\* 38400
4. 57600
5. 115200
0. Return to boot menu

Enter your choice(0-5): 5

Download baudrate is 115200 bps

Please change the terminal's baudrate to 115200 bps and select XMODEM protocol

Press enter key when ready

Now please start transfer file with XMODEM protocol

If you want to exit, Press <Ctrl+X>

Loading ...CCCCDone!

Will you Update Basic BootRom? (Y/N):Y

Updating Basic BootRom...Done!

Updating extended BootRom? (Y/N):Y

Updating extended BootRom...Done!

Please change the terminal's baudrate to 38400 bps, press ENTER when ready.  
Press enter key when ready

1. Update full BootRom
2. Update extended BootRom
3. Update basic BootRom
0. Return to boot menu

Enter your choice(0-3): 0

BOOT MENU

1. Download application file to flash
2. Select application file to boot
3. Display all files in flash
4. Delete file from flash
5. Modify BootRom password
6. Enter BootRom upgrade menu
7. Skip current system configuration
8. Set BootRom password recovery
9. Set switch startup mode
0. Reboot

Enter your choice(0-9): 1

1. Set TFTP protocol parameters
2. Set FTP protocol parameters
3. Set XMODEM protocol parameters
0. Return to boot menu

Enter your choice(0-3): 3

Please select your download baudrate:

1. 9600
2. 19200
- 3.\* 38400
4. 57600
5. 115200
0. Return to boot menu

Enter your choice(0-5): 5

Download baudrate is 115200 bps

Please change the terminal's baudrate to 115200 bps and select XMODEM protocol

Press enter key when ready

Are you sure to download file to flash? Yes or No (Y/N):Y

Now please start transfer file with XMODEM protocol

If you want to exit, Press <Ctrl+X>

Loading ...CCCCCCCCDone!

Load File name : default\_file

Free space: 73922560 bytes

Writing flash.....  
.....Done!

Please input the file attribute (Main/Backup/None) m

The attribute of S2900-CMW520-R1101P09.bin is changed from main to none!

Done!

Your baudrate should be set to 38400 bps again!

Press enter key when ready

BOOT MENU

1. Download application file to flash
2. Select application file to boot
3. Display all files in flash
4. Delete file from flash
5. Modify BootRom password
6. Enter BootRom upgrade menu
7. Skip current system configuration
8. Set BootRom password recovery
9. Set switch startup mode
0. Reboot

Enter your choice(0-9): 0

Starting.....

\*\*\*\*\*

\*\*\*\*\*  
Copyright(c) 2004-2011 3Com Corp. and its licensors. All rights reserved.

Creation Date : Dec 6 2011  
CPU L1 Cache : 32KB  
CPU Clock Speed : 333MHz  
Memory Size : 128MB  
Flash Size : 128MB  
CPLD Version : 002  
PCB Version : Ver.B  
Mac Address : 4001C67AA1C0

the normal and back basic is not equal, update back basic....  
the normal and back extend is not equal, update back extend....  
Press Ctrl-B to enter Extended Boot menu...0  
Starting to get the main application file--flash:/default\_file!.....  
.....  
The main application file is self-decompressing.....  
.....Done!  
System is starting...  
Startup configuration file does not exist.  
User interface aux0 is available.

Press ENTER to get started.

Login authentication

Username:admin

Password:

<3Com Baseline Switch>

#Apr 26 12:00:36:894 2000 3Com Baseline Switch SHELL/4/LOGIN:

Trap 1.3.6.1.4.1.43.45.1.10.2.2.1.1.3.0.1<h3cLogIn>:admin login from Console

%Apr 26 12:00:37:63 2000 3Com Baseline Switch SHELL/4/LOGIN: admin login from au

x0?

User view commands:

- initialize Delete the startup configuration file and reboot system
- ipsetup Specify the IP address of the VLAN interface 1
- password Specify password of local user
- ping Ping function
- quit Exit from current command view
- reboot Reboot system
- summary Display summary information of the device.
- upgrade Upgrade the system boot file or the Boot ROM program

<3Com Baseline Switch>

<3Com Baseline Switch>summary

```

Select menu option:      Summary
IP Method:               DHCP
IP address:              10.10.1.153
Subnet mask:             255.255.255.0
Default gateway:        10.10.1.2

```

Current boot app is: flash:/default\_file  
Next main boot app is: flash:/default\_file  
Next backup boot app is: NULL

3Com Corporation

3Com Baseline Switch 2952-SFP Plus Software Version 5.20 Release 1111

Copyright (c) 2004-2012 3Com Corp. and its licensors. All rights reserved.

3Com Baseline Switch 2952-SFP Plus uptime is 0 week, 0 day, 0 hour, 0 minute

3Com Baseline Switch 2952-SFP Plus  
128M bytes DRAM  
128M bytes Nand Flash Memory  
Config Register points to Nand Flash

Hardware Version is REV.B

CPLD Version is 002  
Bootrom Version is 151  
[SubSlot 0] 48GE+4SFP Hardware Version is REV.B

<3Com Baseline Switch>

#Apr 26 12:05:02:265 2000 3Com Baseline Switch SHELL/4/LOGIN:

Trap 1.3.6.1.4.1.43.45.1.10.2.2.1.1.3.0.1<h3cLogIn>:admin login from Web

%Apr 26 12:05:02:434 2000 3Com Baseline Switch WEB/4/WEBOPT\_LOGIN\_SUC:admin logged in from 10.10.1.173

<3Com Baseline Switch>

\*\*\*\*\*  
\* Copyright (c) 2004-2012 3Com Corp. and its licensors. All rights reserved. \*  
\* This software is protected by copyright law and international treaties. \*  
\* Without the prior written permission of 3Com Corporation and its licensors, \*  
\* any reproduction republication, redistribution, decompiling, reverse \*  
\* engineering is strictly prohibited. Any unauthorized use of this software \*  
\* or any portion of it may result in severe civil and criminal penalties, and \*  
\* will be prosecuted to the maximum extent possible under the applicable law.\*  
\*\*\*\*\*

User interface aux0 is available.

Please press ENTER.

Login authentication

Username:admin

Password:

<3Com Baseline Switch>

#Apr 26 13:43:03:157 2000 3Com Baseline Switch SHELL/4/LOGIN:

Trap 1.3.6.1.4.1.43.45.1.10.2.2.1.1.3.0.1<h3cLogIn>:admin login from Console

%Apr 26 13:43:03:327 2000 3Com Baseline Switch SHELL/4/LOGIN: admin login from a  
ux0?

User view commands:

- initialize Delete the startup configuration file and reboot system
- ipsetup Specify the IP address of the VLAN interface 1
- password Specify password of local user
- ping Ping function
- quit Exit from current command view
- reboot Reboot system
- summary Display summary information of the device.
- upgrade Upgrade the system boot file or the Boot ROM program

<3Com Baseline Switch>initialize

The startup configuration file will be deleted and the system will be rebooted.

Continue? [Y/N]:y

#Apr 26 13:43:16:294 2000 3Com Baseline Switch DEV/1/REBOOT:

Reboot device by command.

%Apr 26 13:43:16:396 2000 3Com Baseline Switch DEV/4/SYSTEM REBOOT:

System is rebooting now.

Starting.....

```

*****
*
*          3COM 2952-SFP Plus BOOTROM, Version 151
*
*
*****

```

Copyright(c) 2004-2011 3Com Corp. and its licensors. All rights reserved.

```

Creation Date      : Dec  6 2011
CPU L1 Cache      : 32KB
CPU Clock Speed   : 333MHz
Memory Size       : 128MB
Flash Size        : 128MB
CPLD Version      : 002
PCB Version       : Ver.B
Mac Address       : 4001C67AA1C0

```

Press Ctrl-B to enter Extended Boot menu...0

Please input BootRom password:

BOOT MENU

1. Download application file to flash
2. Select application file to boot
3. Display all files in flash
4. Delete file from flash
5. Modify BootRom password
6. Enter BootRom upgrade menu
7. Skip current system configuration
8. Set BootRom password recovery
9. Set switch startup mode
0. Reboot

Enter your choice(0-9): 1

1. Set TFTP protocol parameters
2. Set FTP protocol parameters
3. Set XMODEM protocol parameters
0. Return to boot menu

Enter your choice(0-3): 3

Please select your download baudrate:

- 1. 9600
- 2. 19200
- 3.\* 38400
- 4. 57600
- 5. 115200
- 0. Return to boot menu

Enter your choice(0-5): 5

Download baudrate is 115200 bps

Please change the terminal's baudrate to 115200 bps and select XMODEM protocol

Press enter key when ready

Are you sure to download file to flash? Yes or No (Y/N):Y

Now please start transfer file with XMODEM protocol

If you want to exit, Press <Ctrl+X>

Loading ...CCCCC Done!

Load File name : default\_file

The file already exists, will you overwrite it? (Y/N):Y

Deleting.....

.....Done!

Free space: 73922560 bytes

Writing flash.....

.....Done!

The attribute of default\_file keeps main attribute!

Done!

Your baudrate should be set to 38400 bps again!

Press enter key when ready

BOOT MENU

- 1. Download application file to flash
- 2. Select application file to boot
- 3. Display all files in flash
- 4. Delete file from flash
- 5. Modify BootRom password
- 6. Enter BootRom upgrade menu
- 7. Skip current system configuration
- 8. Set BootRom password recovery
- 9. Set switch startup mode
- 0. Reboot

Enter your choice(0-9): 0

Starting.....

```

*****
*
*           3COM 2952-SFP Plus BOOTROM, Version 151           *
*
*****

```

Copyright(c) 2004-2011 3Com Corp. and its licensors. All rights reserved.

```

Creation Date      : Dec  6 2011
CPU L1 Cache      : 32KB
CPU Clock Speed   : 333MHz
Memory Size       : 128MB
Flash Size        : 128MB
CPLD Version      : 002
PCB Version       : Ver.B
Mac Address       : 4001C67AA1C0

```

Press Ctrl-B to enter Extended Boot menu...0

Starting to get the main application file--flash:/default\_file!.....

.....

The main application file is self-decompressing.....

.....

.....Done!

System is starting...

Startup configuration file does not exist.

User interface aux0 is available.